



X series

X-CUT
Plasma Inverter

**PLASMA CUTTER
MANUAL**

30.0



BOSSWELD *X series*
WELD LIKE A BOSS

Thank you for choosing a BOSSWELD X-CUT 30.0 Inverter DC Plasma Cutter

In this manual you will find instructions on how to set up your plasma cutter along with general plasma cutting information, safety information and helpful tips. We encourage you to go online to our website for more tips and troubleshooting as well as many plasma cutting resources.

The BOSSWELD X-CUT 30.0 is the latest in IGBT Inverter cutting technology, this lightweight plasma cutter enables the user to complete high quality cutting of ferrous and non ferrous metals up to 30mm with ease. You will be impressed with what this power house can cut.

We truly hope you enjoy using your plasma cutter



P

PLASMA CUTTING

- Wide range of uses to cut conductive metals
- Uses an accelerated jet of hot plasma
- High speed/low cost cutting method
- Used extensively replacing gas cutting methods
- Air compressor is required

METAL TYPES

Mild steel, stainless steel & aluminium

CONTENTS	PAGE
WARRANTY	4
BOX CONTENTS	5
WARNINGS	6
MACHINE CARE / SAFETY INSTRUCTIONS	7
WORK AREA SAFETY	8
MAINTENANCE & DISPOSAL / DUTY CYCLE	9
FRONT & REAR PANEL LAYOUT	10
PLASMA SETUP	11-13
PLASMA CUTTING FUNDAMENTALS	14
TIPS FOR PLASMA CUTTING	15
PLASMA TORCH SPARES	16
TROUBLE SHOOTING	17
COMMON WEAR PARTS	18-19



WARRANTY

This warranty is in addition to the statutory warranty provided under Australian Consumer Law, but does not include damage resulting from transport, misuse, neglect or if the product has been tampered with. The product must be maintained as per this manual, and installed and used according to these instructions on an appropriate power supply. The product must be used in accordance with industry standards and acceptable practice.

Special note:

If this machine's duty cycle is exceeded the machine will enter "thermal overload" which will automatically stop the plasma cutting output in order to protect, both the user and the machine. You will know the machine has gone into thermal overload when the overload error indicator light is illuminated. The machine will then cool itself down, and once the overload error indicator light is no longer illuminated, plasma cutting can then re-commence.

Please note. Exceeding the machine's duty cycle, cannot be considered grounds for warranty or return.

This warranty covers the materials used to manufacture the machine and the workmanship used to produce the item. This Warranty does not cover damage caused by:

1. Normal wear and tear due to usage
2. Misuse /abuse or Neglect of the item
3. Transport / handling breakages
4. Lack of maintenance, care and cleaning
5. Environmental factors, such as usage in temperatures exceeding 40 degrees, above 1000mt sea level, rain, water, excessive damp, cold or humid conditions.
6. Improper setup or installation
7. Use on Incorrect voltage or non authorised electrical connections and plugs
8. Use of non standard parts
9. Repair, case opening, tampering with, modifications to any part of the item by non authorised BOSSWELD repairers.

This warranty covers the machine only and does not include Torches, Leads, Earth Clamps, Electrode holders, Plasma Torches, Tig Torches and any of the parts on those items unless there is a manufacturing fault.

1. REGISTRATION

Purchasers are encouraged to register for warranty on our website. www.bossweld.com.au/warranty
Product must be registered to receive full 3 year warranty. 2 year standard warranty applies if the product is not registered online.

2. TIME PERIOD - 3 Years (when registered online)

When the plasma cutter *has been registered online*, a warranty claim must be made within 3 years from the date of purchase. If the plasma cutter *has not been registered online*, a warranty claim must be made within 2 years from the date of purchase. Any claim must include proof of purchase.

3. HOW TO MAKE A CLAIM - NEED SOME HELP?

- Visit our website www.bossweld.com.au/troubleshooting for many helpful tips and guides to assist with the setup and usage of your new machine. Still stuck...?
- Call the BOSSWELD Helpdesk on 1300 899 710 for over the phone assistance.
- If the machine is not operational then return the item to the place of purchase.

BOSSWELD MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED. THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHERS, INCLUDING, BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

DO NOT GRIND YOUR PLUG
This will void any warranty on your machine



BOSSWELD X-CUT 30.0 Inverter DC Plasma Cutter Box Contents

1. BOSSWELD X-CUT 30.0 Inverter DC Plasma Cutter
2. Plasma Torch
3. Earth Lead
4. Air regulator (built in)
5. Carry Strap
6. Torch Spares (not shown)
7. Owners Manual (not shown)





WARNING

The device and packaging material are not toys! Children must not be allowed to play with the machine and its accessories. Plastic parts and packaging are choking risks for children.

- Open the packaging and remove the plasma cutter carefully.
- Check that the delivery is complete.
- If possible, store the packaging until the warranty period has expired.

PERSONAL PROTECTIVE EQUIPMENT (PPE)



GLOVES AND PROTECTIVE CLOTHING

Use protective gloves and fire resistant protective clothing when plasma cutting. Avoid exposing skin to ultraviolet rays produced by the arc.



WELDING HELMET / SAFETY GLASSES

Under no circumstances should the plasma cutter be operated unless the operator is wearing goggles to protect the eyes and face. There is serious risk of eye damage if a helmet is not used. The sparks and metal projectiles can cause serious damage to the eyes and face. The light radiation produced by the arc can cause damage to eyesight, and burns to skin.



Never remove the welding helmet whilst plasma cutting.



OTHER PERSONS

Ensure that other persons are screened from the plasma sparks and are at least 15 metres away from the work piece. Always ensure that cutting area is screened from onlookers, or people just passing by. Use screens if necessary, or non-reflecting welding curtain. Do not let children or animals have access to the plasma cutting equipment or to the work area.



SWITCHING OFF

When the operator has finished cutting they must switch the Plasma cutter off. When leaving the Plasma cutter unattended, move the ON/OFF switch to the OFF position and disconnect the plasma from the electrical mains supply. Do not leave hot material unattended after cutting.



FUMES & GASES ARE DANGEROUS

Smoke and gas generated whilst plasma cutting can be harmful to people's health. Plasma cutting produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Do not breathe the smoke and gas generated whilst plasma cutting, keep your head out of the fumes
- Keep the working area well ventilated, use fume extraction or ventilation to remove plasma cutting fumes and gases.
- In confined or heavy fume environments always wear an approved air-supplied respirator. Plasma cutting fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not cut in locations near de-greasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapours to form highly toxic and irritating gases.
- Materials such as galvanized, lead, or cadmium plated steel, containing elements that can give off toxic fumes when cut. Do not cut these materials unless the area is very well ventilated, and or wearing an air supplied respirator.



MACHINE CARE / SAFETY

Keep the plasma torch, earth clamp and cables in good condition. Failure to do this can result in poor cutting quality, which could be dangerous in structural situations.

Prior to use, check for breakage of parts and any other conditions that may affect operation of the plasma cutter. Any part of the plasma cutter that is damaged should be carefully checked to determine whether it will perform its intended function whilst being safe for the operator. Any part that is damaged should be properly repaired, or replaced by an authorised service centre.

IMPROPER USE

It is hazardous to use the plasma machine for any work other than that for which it was designed e.g. do not use plasma for thawing pipes.

HANDLING

Ensure the handle is correctly fitted. As plasma machines can be heavy, always use safe lifting practices when lifting.

POSITION AND HANDLING

To reduce risk of the machine being unstable / danger of overturning, position the plasma cutting machine on a horizontal surface that is able to support the machine weight. Operators **MUST NOT BE ALLOWED** to cut in raised positions unless safety platforms are used.



SAFETY INSTRUCTIONS

WARNING

The user of this plasma cutter is responsible for their own safety and the safety of others. It is important to read, understand and respect the contents of this user guide. When using this plasma cutter, basic safety precautions, including those in the following sections must be followed to reduce the risk of fire, electric shock and personal injury. Ensure that you have read and understood all of these instructions before using this plasma cutter. Persons who are not familiar with this user guide should not use this plasma cutter. Keep this booklet in a safe place for future reference.

TRAINING





The operator should be properly trained to use the plasma cutting machine safely and should be informed about the risks relating to plasma cutting procedures. This user guide does not attempt to cover plasma cutting technique. Training should be sought from qualified / experienced personnel on this aspect, especially for any cuts requiring a high level of integrity for safety.

SERIOUS FIRE RISK

The plasma cutting process produces sparks, droplets of fused metal, metal projectiles and fumes. This constitutes a serious fire risk. Ensure that the area in which plasma cutting will be undertaken is clear of all inflammable materials. It is also advisable to have a fire extinguisher, and a welding blanket on hand to protect work surfaces.



WORK AREA

-  Ensure a clear, well lit work area with unrestricted movement for the operator.
-  The work area should be well ventilated, as plasma cutting emits fumes which can be dangerous.
-  Always maintain easy access to the ON/OFF switch of the plasma cutter, and the electrical mains supply.
-  Do not expose the Plasma cutter to rain and do not operate in damp or wet locations

Where plasma cutting must be undertaken in environments with increased risk of electric shock, confined spaces or in the presence of flammable or explosive materials, it is important that the environment be evaluated in advance by an “expert supervisor”. It is also recommended that plasma cutting in these circumstances be carried out in the presence of persons trained to intervene in emergencies.

AVOID ELECTRICAL CONTACT

Use adequate electrical insulation with regard to the electrode, the work piece and any accessible earthed metal parts in the vicinity. Avoid direct contact with the plasma arc. The no load voltage between the earth clamp and the electrode can be dangerous under certain circumstances.

Note: For additional protection from electric shock. It is recommended that this plasma cutter be used in conjunction with a residual current device (RCD) with rated residual current of 30MA or less.

In general the use of extension leads should be avoided. If used however, ensure that the extension lead is used with the plasma cutter is of a suitable current rating and heavy duty in nature that **MUST** have an earth connection. If using the plasma cutter outdoors, ensure that the extension lead is suitable for outdoor use. Always keep extension leads away from the plasma cutting zone, moisture and any hot materials.

CUTTING SURFACES

Do not cut containers or pipes that hold, or have held, flammable liquids or combustible gases or pressure. Do not cut on coated, painted or varnished surfaces as the coatings may ignite, or can give off dangerous fumes.

WORK PIECE

When cutting, the work piece will remain at high temperature for a relatively long period. The operator must not touch the cut or the work piece unless wearing welding gloves. Always use pliers or tongs. Never touch the cut material with bare hands until it has completely cooled.



MAINTENANCE

WARNING

Before starting any cleaning, or maintenance procedures on the plasma cutting machine, make sure that it is switched OFF and disconnected from the mains supply.

There are no user serviceable parts inside the plasma cutter. Refer to a qualified service personnel if any internal maintenance is required. After use, wipe the plasma cutter down with a clean soft dry cloth.

Regular inspection of the supply cord is required and if damaged is suspected, it must be immediately replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard

STORAGE/ TRANSPORT

Store the plasma cutter and accessories out of children’s reach in a dry place. If possible store the plasma cutter in the original packaging. The appliance must unconditionally be secured against falling or rolling over during transport.



DISPOSAL

DISPOSING OF THE PACKAGING

Recycling packaging reduces the need for landfill and raw materials. Reuse of the recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

DISPOSING OF THE PLASMA CUTTER

Plasma cutters that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.

DUTY CYCLE:

Special note:

If this machines duty cycle is exceeded the machine will enter “thermal overload” which will automatically stop the plasma cutting output in order to protect, both the user and the machine. You will know the machine has gone into thermal overload when the overload error indicator light is illuminated. The machine will then cool itself down, and once the overload error indicator light is no longer illuminated, plasma cutting can then re-commence.

Please note. Exceeding the machine’s duty cycle, cannot be considered grounds for warranty or return.

The term duty cycle indicates the percentage plasma cutting time available at the output current for each 10 min period over 4 hours,

The specification plate on the machine list two given ratings at a given current and voltage.

NOTE: Amps refer to the Current setting

20%	100%
40 - Amps	25-Amps
96.0 Volts	92.0 Volts

For example this means when the machine is set at a current of 40 Amps it can only cut for Two Minutes in a Ten minute period.

The power source is protected by a built in temperature protection device,

This will activate if the machine is operated in excess of its amperage and duty cycle rating.



The Overload Error Indicator light indicates

- Over temperature
- Duty cycle exceeded

Points to Current machine will output

INVERTER DC PLASMA CUTTER		BOSSWELD X_{series}	
Bossweld XCUT 30.0		PART NO.	695065
		STANDARD	EN 60974-1:2012
	U₀=450V	20A/88V-65A/106V	
		X	90% 100%
		I₂	65A 61A
		U₂	106V 104V
	U_i=415V	I_{1max}=18A	I_{1eff}=17.1A
IP21S		24kg	


Duty Cycle

Amperage / Current

Voltage


FRONT PANEL

1. Power Indicator Light
2. Overload Error Indicator
3. Cutting Circuit Operational Lamp
4. Cutting Indicator Light
5. Cut / Aircheck Switch
6. Current Adjustment Knob
7. Plasma Torch Central Connector
8. Earth Lead Connection Socket




REAR PANEL

9. Mains Power Switch
10. 415V AC Mains Power Cord
11. Cooling Fan
12. Air Filter/Water Separator Drain
13. Air Regulator Pressure Adjustment
14. Air Pressure Gauge (view on side of machine)
15. Compressed Air Inlet



SET UP X-CUT 30.0 Inverter DC Plasma Cutter

1. Install the compressed air hose to the connector at the rear panel of the machine to the Compressed Air Inlet.

2. Connect earth Clamp to the  terminal

4. Plug the machine input power lead into 3 Phase power, ensuring that the Mains Power Switch is OFF.

3. Connect the Plasma torch to the Plasma Torch Central Connector.




Ensure all plasma torch parts are correctly fitted.



1 Install the compressed air hose to the connector at the rear panel of the machine to the Compressed Air Inlet.



3 Connect the Plasma torch to the Plasma Torch Central Connector.




2 Connect the earth lead to the Earth Lead Connection Socket (positive) and connect earth clamp to work piece ensuring that the clamp makes good contact with bare metal.



4 Plug the machine input power lead into the wall socket, ensuring that the Mains Power Switch is OFF.

*Primary Plug not supplied.
Plugs must be fitted by suitably qualified personnel*

SET UP X-CUT 30.0 Inverter DC Plasma Cutter- continued

5 Make sure air compressor is turned on and capable of 7-8 CFM (cubic feet per minute) free air delivery, or 200 LPM (litres per minute)



8 Select your required current turning the Current Adjustment Knob. If the plasma is struggling to penetrate, increase amperage by turning the Current Adjustment Knob. Set the CUT / AIRCHECK switch to CUT,



6 Set Air pressure to 60-80 PSI, 410-550 KPA or 041-0.55 MPA



9 The plasma torch trigger switch has a safety trigger to prevent accidental triggering. Slide the safety switch back and depress switch.



7 Switch ON the machine using Mains Power Switch. Set the CUT / AIRCHECK switch to AIRCHECK and test the Air Pressure



10 Depress switch and the pilot arc fires from the nozzle. Care must be taken when depressing trigger switch. This arc is designed to burn through contamination, paint or rust to allow the main cutting arc to connect with bare metal. Continued depressing of the switch away from cutting surface will reduce the effectiveness of the consumables and greatly reduce their life span.

SET UP X-CUT 30.0 Inverter DC Plasma Cutter- continued



- 11** After the cutting arc starts, slowly start moving the torch across the work piece.
Note: Always start the Arc on a material edge or drill a small hole in the work piece to start Arc.




- 14** At the end of the cut pause to allow the plasma to sever the last part.



- 12** Adjust the cutting speed so that the sparks go through the work piece and out the bottom of the cut.



- 15** Regularly inspect your consumables for wear. Replace when excessive wear is apparent. When replacing, ensure all plasma torch consumables are correct.




- 13** If the sparks are blown out toward the torch or at a great angle below the work piece, reduce the cutting speed.

WARNING: Before disassembling or replacing torch components, ensure machine is turned off and plug is disconnected/removed from mains.

Note: Pictures may vary from your machine model

PLASMA CUTTING FUNDAMENTALS



The Plasma arc process has always been seen as an alternative to the oxy-fuel process. The plasma arc cutting process is illustrated below. The basic principle is that the arc formed between the electrode and the workpiece is constricted by a fine bore, copper nozzle. This increases the temperature and velocity of the plasma emanating from the nozzle. The temperature of the plasma is in excess of 20 000°C and the velocity can approach the speed of sound. When used for cutting, the plasma gas flow is increased so that the deeply penetrating plasma jet cuts through the material and molten material is removed in the efflux plasma. The process differs from the oxy-fuel process in that the plasma process operates by using the arc to melt the metal whereas in the

oxy-fuel process, the oxygen oxidises the metal and the heat from the exothermic reaction melts the metal. Thus, unlike the oxy-fuel process, the plasma process can be applied to cutting metals which form refractory oxides such as stainless steel, aluminium, cast iron and non-ferrous alloys.

POWER SOURCE

The power source required for the plasma arc process must have a drooping characteristic and a high voltage. Although the operating voltage to sustain the plasma is typically 50 to 60V, the open circuit voltage needed to initiate the arc can be up to 450V DC.

On initiation, the pilot arc is formed within the body of the torch between the electrode and the nozzle.

For cutting, the arc must be transferred to the workpiece in the so-called 'transferred' arc mode.


The electrode has a negative polarity and the workpiece a positive polarity so that the majority of the arc energy (approximately two thirds) is used for cutting.

GAS COMPOSITION

In the conventional system using a tungsten electrode, the plasma is inert, formed using argon, argon-H₂ or nitrogen. However oxidising gases, such as air or oxygen, can be used but the electrode must be copper with hafnium. The plasma gas flow is critical and must be set according to the current level and the nozzle bore diameter. If the gas flow is too low for the current level, or the current level too high for the nozzle bore diameter, the arc will break down forming two arcs in series, electrode to nozzle and nozzle to workpiece. The effect of 'double arcing' is usually catastrophic with the nozzle melting.

CUT QUALITY

The quality of the plasma cut edge is similar to that achieved with the oxy-fuel process. However, as the plasma process cuts by melting, a characteristic feature is the greater degree of melting towards the top of the metal resulting in top edge rounding, poor edge squareness or a bevel on the cut edge. As these limitations are associated with the degree of constriction of the arc, several torch designs are available to improve arc constriction to produce more uniform heating at the top and bottom of the cut.



Plasma is commonly known as the 4th matter of state the first being solid, then liquid, gas and then plasma. each matter changes from one state to another through the introduction of heat

TIPS FOR PLASMA CUTTING

COMPRESSED AIR REQUIREMENTS

1. A reliable and consistent supply of clean dry compressed air is essential for proper operation.
2. The compressed air supply must have filtration in the line feeding the power source, both a standard water trap (sintered bronze filter) and also a coalescing filter (for oil in air).
3. The unit requires a minimum (FAD) Free Air Delivery of 200LPM and 60 – 80 PSI pressure. This normally means the compressor must be a belt drive model or if a direct drive it must have a motor power of 2.5HP or greater.
4. The air must be dry and free of oil and moisture (normally a symptom of older, worn out compressors). The air hose must also be of sufficient size (3/8"/10mm minimum) to supply the machine.


Note: Alloys generally take 50% more amperage for the thickness than steel

PIERCING THE WORK

Many inexperienced users try to pierce the metal by coming straight down perpendicular (90°) to the work. This results in molten metal being blown back into the torch. A better method is to approach the metal at a slight angle (60°) towards the direction of the cut. This way, the molten metal is blown away from the torch.

Handheld Operation – how it works

In a typical handheld plasma system, such as our Bossweld X-Cut 30.0 Air Plasma, the electrode and nozzle consumable parts are in contact with one another inside the torch when in the OFF state. When the trigger is squeezed, the power supply produces a DC current that flows through this connection, and also initiates the plasma gas flow. Once the plasma gas (compressed air) builds up enough pressure, the electrode and nozzle are forced apart, which causes an electrical spark that converts the air into a plasma jet. The DC current flow then switches from electrode to nozzle, to a path between the electrode and work piece. This current and airflow continues until the trigger is released.



PLASMA TORCH PT60

PART NO.	DESCRIPTION
94.0016	Bossweld PT60 Plasma Cutting Torch suits X-CUT 30.0



PART NO.	DESCRIPTION
96.60432	Double Pointed Stand Off Guide, Suits PT40/PT60



PART NO.	DESCRIPTION
96.60389	Retaining Cap 6 holes, Suits PT40/PT60, S45



PART NO.	DESCRIPTION
96.51318.08	Tip Contact B/Strike, 0.8mm 20-30A, Suits PT25/PT40/PT60
96.51318.09	Tip Contact B/Strike, 0.9mm 30-40A, Suits PT40/PT60
96.51318.11	Tip Contact B/Strike, 1.1mm 50-65A, Suits PT60



PART NO.	DESCRIPTION
96.51314.09	Tip Ext Contact B/Strike, 0.9mm 30-40A, Suits PT40/PT60



PART NO.	DESCRIPTION
96.60028	Swirl Ring, Suits PT25/PT40/PT60, S45/S54



PART NO.	DESCRIPTION
96.52582	Electrode back striking, Suits PT25/PT40/PT60



PART NO.	DESCRIPTION
96.52583	Electrode Extended back striking, Suits PT25/PT40/PT60



Central Adaptor



TROUBLE SHOOTING

Problem	What to do
Power indicator is not lit, fan does not work and no output current	<ol style="list-style-type: none"> 1. Check that the plasma is plugged into the mains outlet and is switched on. 2. Check that the mains fuse or breaker has not operated. 3. Check that the main switch on the rear of the unit is in the on position.
Power indicator is lit, fan works, no output current	<ol style="list-style-type: none"> 1. Check the plasma cables are connected correctly. 2. Check the output connectors are not disconnected or damaged. 3. Check that the earth clamp is connected securely to the workpiece and that the contact point is clean of paint or rust.
Over temperature indicator is on, no output current	<ol style="list-style-type: none"> 1. Duty cycle of the unit has been exceeded. Allow the unit to cool for 20 minutes.
Output current is not stable.	<ol style="list-style-type: none"> 1. Check mains voltage is constant. 2. Check the torch cable connector is tight in the socket. 3. Check the earth clamp connection to the workpiece.
Power lamp and temperature lamp on	<ol style="list-style-type: none"> 1. Air flow blocked – check for blocked air flow around the unit and correct condition. 2. Fan blocked – check and correct condition. 3. Unit is overheated - let it cool down for at least 5 minutes. Make sure the unit has not been operated beyond the duty cycle limit, refer to parameters 4. Faulty components in unit – return for repair or have qualified technician repair as per service manual.
Torch fails to ignite the arc when torch switch activated	<ol style="list-style-type: none"> 1. Faulty torch parts – inspect torch parts and replace if necessary. 2. Gas pressure too high or too low – adjust to proper pressure. 3. Faulty components in unit – adjust for repair or have qualified technician repair per service manual.

OPERATIONAL ENVIRONMENT

- Height above sea level $\leq 1000\text{m}$
- Operation temperature range $-10\sim+40^{\circ}\text{C}$
- Air relative humidity is below 90% (20°C)
- Preferably sit the machine above floor level, ensure the maximum angle does not exceed 15 degrees.
- Protect the machine against heavy rain and against direct sunshine.
- The content of dust, acid, corrosive gas in the surrounding air or substance must not exceed normal standard.
- Take care that there is sufficient ventilation during plasma cutting. There must be at least 30cm free distance between the machine and wall.

MACHINE CONSUMABLE OPTIONS



Bossweld Plasma Air Filter

The Bossweld Air Filter removes condensed moisture, oils, and particulates from air supply. It is ideal for all plasma cutting applications.

CODE	DESCRIPTION
94.M26	Bossweld Plasma Air Filter M26
94.M723	Bossweld Replacement Element for M26



Bossweld Universal Welders Trolley

Multi purpose welder trolley that suits most Bossweld welding machines.

Features

- 45kg capacity
- 3 storage levels
- Sturdy formed steel construction
- Cylinder holder accepts D and E size gas cylinders and comes with 2 safety chains
- Large 7.5cm casters for easy movement
- Welders sits at an angle for easy access to controls
- Handy cable hangers
- Overall dimension - 70.5cm (L) x 41.9cm (W) x 77.5cm (H)

CODE	DESCRIPTION
600311	Bossweld Welder Trolley Universal



Bossweld 16inch Welding Gloves

BossSafe 16 inch welding gloves available in black and gold cow split leather.

CODE	DESCRIPTION
700010	Bossweld 16" Black & Gold Welding Glove



Bossweld Gas Welding Flip-Up Goggles

Lightweight goggle used for Oxy/Acetylene and Oxy/LPG cutting and brazing

Features

- Light weight
- Flip up lenses
- Comfortable fit to face
- Elastic head straps

Applications

- Eye protection during Oxy/Acetylene and Oxy/LPG cutting and brazing
- Plasma cutting

CODE	DESCRIPTION
700055	Bossweld Gas Welding Flip-up Goggles Shade 5



Bossweld Engineers Chalk

High quality soapstone engineers chalk used for marking steel in general engineering & boilermaking.

Features

- 75mm long
- 10 x 5mm or 10 x 10mm
- Semi permanent marking of steels

CODE	DESCRIPTION
800020	Bossweld Engineers Chalk 75 x 10 x 10mm
800022	Bossweld Engineers Split Chalk 75 x 10 x 5 mm

SAFETY EQUIPMENT



CODE	DESCRIPTION
700001M	Bossweld Leather Welder's Jacket (Medium)
700001L	Bossweld Leather Welder's Jacket (Large)
700001XL	Bossweld Leather Welder's Jacket (X Large)
700001XXL	Bossweld Leather Welder's Jacket (XX Large)
700001XXXL	Bossweld Leather Welder's Jacket (XXX Large)

Bossweld Leather Welders Jacket

Chrome leather welding jacket with metal snaps. Unlined, the jacket has heavy duty sewing.

Features

- Heavy duty chrome leather
- Double studs for extra protection
- Several sizes available
- Heavy duty sewing



CODE	DESCRIPTION
700255M	Bossweld FR-40 Jacket w/ Leather Sleeve - M
700255L	Bossweld FR-40 Jacket w/ Leather Sleeve - L
700255XL	Bossweld FR-40 Jacket w/ Leather Sleeve - XL

Bossweld FR40 Welders Jacket with leather Sleeve

Manufactured from a lightweight, flame retardant material, provides protection for the upper body & arms, with chrome leather sleeves.

Features

- Light weight composite welders jacket
- Flame retardant material
- Several sizes available
- Leather sleeves for excellent protection



CODE	DESCRIPTION
700002	Bossweld Chrome Leather Full Apron 60 x 90cm

Bossweld Chrome Leather Apron

Chrome leather full apron. Two piece style with heavy duty sewing. 60cm x 90cm.

Features

- Heavy duty chrome leather
- Leather neck and waist adjustable strap
- Heavy duty sewing for reliability
- Excellent protection (60cm x 90cm)



OTHER PRODUCTS IN OUR RANGE

- ELECTRODES
- TIG RODS
- WELDING HELMETS
- WELDING MACHINES
- TORCH SPARE PARTS
- WELDING ACCESSORIES
- MIG WIRE
- GAS EQUIPMENT
- WELDING SAFETY
- MIG TORCHES
- TIG TORCHES
- WELDING CABLE

BOSSWELD
WELD LIKE A BOSS

X series