

HOLEMAKER HMPRO65

Holemaker Portable Magnetic Drilling Machine

OPERATOR'S MANUAL

⚠ WARNING!

BEFORE USE, ENSURE EVERYONE USING THIS MACHINE READS AND UNDERSTANDS ALL SAFETY AND OPERATING INSTRUCTIONS IN THIS MANUAL .



EYE PROTECTION
REQUIRED



HEARING PROTECTION
REQUIRED




NEVER PLACE
FINGERS NEAR
CUTTING AREA OR
MACHINE ARBOR



LINE VOLTAGE
PRESENT



BEWARE OF
ROTATING
MACHINE PARTS



Serial # _____

Date of Purchase _____

LIMITED WARRANTY

Industrial Tool & Machinery Sales (hereinafter referred to as ITMS) will, within twelve (12) months from the original date of purchase, repair or replace any goods found to be defective in materials or workmanship.

This warranty is void if the item has been damaged by accident, neglect, improper service or other causes not arising out of defects in materials or workmanship. This warranty does not apply to machines and/or components which have been altered, changed, or modified in any way, or subjected to overloading or use beyond recommended capacities and specifications. Worn componentry due to normal wear and tear is not a warranty claim. Goods returned defective shall be returned prepaid freight to ITMS or agreed repair agent, which shall be the buyer's sole and exclusive remedy for defective goods. ITMS accepts no additional liability pursuant to this guarantee for the costs of travelling or transportation of the product or parts to and from ITMS or the service agent or dealer, such costs are not included in this warranty.

Our goods come with guarantees which cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and to compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

THE MANUFACTURER RESERVES THE RIGHT TO MAKE IMPROVEMENTS AND MODIFICATIONS TO DESIGN WITHOUT PRIOR NOTICE.

PRODUCTS IMPORTED AND DISTRIBUTED NATIONALLY BY:



INDUSTRIAL TOOL & MACHINERY SALES

18 BUSINESS ST, YATALA QLD 4207

T: 07 3287 1114 E: sales@industrialtool.com.au

F: 07 3287 1115 W: www.industrialtool.com.au

1. GENERAL INFORMATION	3
1.1. Application	3
1.2. Technical data.....	3
1.3. Equipment included	4
1.4. Dimensions	5
1.5. Design	6
2. SAFETY PRECAUTIONS.....	7
3. STARTUP AND OPERATION	9
3.1. Installing and removing the annular cutter.....	9
3.2. Installing and removing the cooling system	10
3.3. Monitoring system of the clamping force	11
3.4. Preparing	11
3.5. Drilling.....	13
3.6. Replacing the motor brushes	15
4. WIRING DIAGRAM	16
5. PARTS LIST	17

1. GENERAL INFORMATION

1.1. Application

The HMPRO65 is a drilling machine designed to drill holes with diameters of up to 65 mm (2.56") to a depth of up to 75 mm (2.95") by using annular cutters.


The electromagnetic base clamps the machine to ferromagnetic surfaces. This makes sure that the operator is safe and the machine works correctly. A safety strap protects the machine from falling in case of a clamping loss.

An optional attachment allows you to drill in pipes.

1.2. Technical data


Voltage	1~ 220–240 V, 50–60 Hz 1~ 110–120 V, 50–60 Hz
Power	1600 W
Tool holder	19 mm (3/4") Weldon
Maximum drilling diameter	65 mm (2.56")
Maximum drilling depth	75 mm (2.95")
Clamping force (surface with the thickness of 25 mm and roughness $R_a = 1.25$)	11,000 N
Electromagnetic base dimensions	90 mm × 180 mm × 48 mm 3.5" × 7.1" × 1.9"
Stroke	95 mm (3.7")
Rotational speed under load	160 rpm 390 rpm
Minimum workpiece thickness	8 mm (0.3")
Protection class	I
Noise level	More than 70 dB
Required ambient temperature	0–40°C (32–104°F)
Weight	17 kg (37.5 lbs)

1.3. Equipment included




1	Drilling machine	1 unit
2	Plastic box	1 unit
3	Cooling system	1 unit
4	Handle	3 units
5	Safety strap	1 unit
6	5 mm hex wrench with a handle	1 unit
–	Operator's Manual	1 unit

1.4. Dimensions



1.5. Design



2. SAFETY PRECAUTIONS

1. Before use, read this Operator's Manual and complete a training in occupational safety and health.
2. Use only in applications specified in this Operator's Manual.
3. Make sure that the machine has all parts and they are genuine and not damaged.
4. Make sure that the specifications of the power source are the same as those specified on the rating plate.
5. Connect the machine to a correctly grounded power source. Protect the power source with a 16 A fuse for 230 V or a 32 A fuse for 115 V. If you are going to work on building sites, supply the machine through an isolation transformer with class II protection only.
6. Set the MAGNET switch to 'O' before you move the machine. Use carrying handle to move the machine.
7. Do not carry the machine by the power cord and do not pull the cord. This can cause damage and electric shock.
8. Keep untrained bystanders away from the machine.
9. Before each use, ensure the correct condition of the machine, power source, power cord, plug, control panel, and tools.
10. Before each use, make sure that no part is cracked or loose. Make sure to maintain correct conditions that can have an effect on the operation of the machine.
11. Keep the machine dry. Do not expose the machine to rain, snow, or frost.
12. Do not stay below the machine that is put at heights.
13. Keep the work area well lit, clean, and free of obstacles.
14. Make sure that the tool is correctly attached. Remove wrenches from the work area before you connect the machine to the power source.
15. Do not use tools that are dull or damaged.
16. Unplug the power cord before you install and remove tools. Use protective gloves to install and remove tools.
17. Unplug the power cord before you manually turn the spindle.
18. Use annular cutters without the pilot pin only when you drill incomplete through holes.
19. Do not make holes whose diameter or depth differ from those specified in the technical data.
20. Do not use near flammable materials or in explosive environments.


21. Do not use on surfaces that are rough, not flat, not rigid, or have rust, paint, chips, or dirt.
22. Do not use the gear switch if the motor is on.
23. Use the safety strap to attach the machine to a stable structure. Put the strap through the hole in the machine body. In the horizontal position, attach the strap to the carrying handle. Do not put the strap into the buckle from the front.
24. Use eye and ear protection and protective clothing. Do not use loose clothing.
25. Be careful on workpieces thinner than 10 mm (0.4"). The clamping force depends on the workpiece thickness and is much lower for thin plates.
26. Each time before you put the machine on the workpiece, rub the workpiece with coarse-grained sandpaper. Make sure that the bottom of the base is in full contact with the workpiece.
27. Do not touch chips or moving parts. Do not let anything catch in moving parts.
28. After each use, remove chips and coolant from the machine and the tool. Do not remove chips with bare hands.
29. Unplug the power cord before you do maintenance or install/remove parts.
30. Repair only in a service center appointed by the seller.
31. If the machine falls, is wet, or has any damage, stop the work and immediately send the machine to the service center for check and repair.
32. Do not leave the machine when it operates.
33. If you are not going to use the machine, remove the tool from the holder. Then, remove the machine from the work area and keep it in a safe and dry place.
34. If you are not going to use the machine for an extended period, put anti-corrosion material on the steel parts.

3. STARTUP AND OPERATION

3.1. Installing and removing the annular cutter

Unplug the power cord and turn the handles to the right (1) to lift the motor. Use gloves to put the correct pilot pin into the annular cutter (2). Use a dry cloth to clean the arbor and the cutter. Put the cutter into the arbor (3) to align the flat surfaces (4) with the screws (5). Use the 5 mm hex wrench to tighten the screws.


To remove the cutter, loosen the screws (5) with the 5 mm hex wrench.



3.2. Installing and removing the cooling system

Attach the bottle to the bracket (1). Attach the hose to the fitting (2).

To remove the bottle, continue in reverse sequence.



3.3. Monitoring system of the clamping force

The drilling machine has a system that monitors the clamping force of the electromagnetic base. The force will be lower if there is rust, paint, chips, or dirt. The force will be lower also if the surface is thin, rough, not flat, not rigid, the voltage is lower than required, or the bottom of the base is worn.

If the clamping force is too low, the system will not allow the machine to operate. Then, after you release the green MOTOR button, the motor stops. This happens on a surface thinner than 5 mm (0.2"). The clamping force is then only about 25% of the force that you can get on a flat plate that is 25 mm (1") thick. Then, to drill on thin plates, press and hold the green MOTOR button.

3.4. Preparing

Before use, clean steel parts, including the spindle, from anti-corrosion material used to preserve the machine for storage and transport.


Attach the handles to the feed shaft.

Select the annular cutter or drill bit that matches the required hole diameter. Use a dry cloth to clean the spindle and the cutter. Then, install the cutter as described before.

Put the machine on a flat ferromagnetic workpiece with the thickness of at least 8 mm (0.3"). Make sure that there is no rust, paint, chips, or dirt. They decrease the clamping force. The force will be lower also if the surface is thin, rough, not flat, not rigid, the voltage is lower than required, or the bottom of the base is worn.

Connect the machine to the power source. Set the MAGNET switch to 'I' to turn on the clamping. Some types of steel (non-ferromagnetic) do not conduct magnetic flux so the machine cannot clamp onto them.

Use the safety strap to prevent fall and injury if the machine loses the clamping. Attach the machine to a stable structure by putting the strap through the hole in the machine body. In the horizontal position, attach the strap to the carrying handle. Make sure that the strap is tight and not twisted. If the machine comes loose from the workpiece and hangs on the strap, replace the strap. Do not put the strap into the buckle from the front.







Turn the handles to the left to put the cutter above the workpiece.

In the vertical position, install the cooling system and fill it with coolant. Do not use only water as the coolant. But you can mix water and drilling oil. Then, make sure that the cooling system works correctly. To do this, lightly loosen the bottle cap and use the lever to open the valve. Then, turn the handles to the left to apply a light pressure on the pilot pin. The coolant should fill the system and start flowing from the cutter.

The cooling system works by gravity. Thus, in the inverted or horizontal position, use coolants under pressure or in the form of spray or paste.


3.5. Drilling

Set the speed based on the table that follows.

Tool	Hole diameter		Rotational speed* [rpm]	Gear switch setting
	[mm]	[in]		
HSS annular cutter	12–30	0.47–1.18	390	
	30–65	1.18–2.56	160	
TCT annular cutter	12–34	0.47–1.34	390	
	34–65	1.34–2.56	160	

* For a sharp tool and mild steel with a strength $R_m < 500 \text{ N/mm}^2$ (70,000 psi), such as St0 (S185), St3S (S235JR), or St4W (S275JO)

Turn the gear switch as shown in the figure until you feel resistance. Incorrect setting can damage the gearbox.



Steel with a strength $R_m \geq 500 \text{ N/mm}^2$ (70,000 psi), such as St5 (E295), 18G2A (S355N), or 45 (C45), requires lower speeds. If the speed is too high or too low for the workpiece strength and the type/diameter of the tool, the tool will wear faster or be unable to drill the hole.



Press the green MOTOR button to start the motor. Turn the handles to the left to put the tool into the workpiece.

If the motor does not start, check the condition of the brushes. If the brushes are shorter than 5 mm, replace them with new ones.



When the annular cutter goes through the workpiece, the slug core is pushed out with a large force.

When you use an annular cutter, drill only through holes. For incomplete through holes do not use the pilot pin.



Keep the machine in the same position until the hole is made.

If you are going to drill holes deeper than 50 mm (2"), retract the tool above the workpiece as often as possible. This allows chips to be removed from the hole. If the grooves of the tool are clogged, turn off the motor and use a brush to clean them.

After you get to the depth of 40 mm (1.6"), retract the tool above the workpiece as often as possible. Then, manually apply the coolant from the bottle into the drilling area.

After the hole is made, retract the tool from the workpiece, and press the red MOTOR button to turn off the motor. Before you move the machine, set the MAGNET switch to 'O' to turn off the base.


After the work is finished and the motor turned off, set the gear switch to the opposite position. Then, turn on the motor and let it operate for a while with no load to improve lubrication. Next, turn off the motor and the base, and then unplug the power cord. Clean the machine and the tool, and then remove the machine from the work area.

Tighten the bottle cap, close the valve, and then press the pilot pin to remove the coolant that remains in the cooling system. Before you put the machine into the box, remove the bottle, and use gloves to remove the tool from the holder.


3.6. Replacing the motor brushes

Every 100 work hours, check the condition of the brushes. To do this, unplug the power cord and remove the cover (1). Lift the spring (2) and remove the brush. If the brush is shorter than 5 mm (0.2"), replace the two brushes with new ones.


Install in reverse sequence. Then, let the motor operate with no load for 20 minutes.




4. WIRING DIAGRAM



5. PARTS LIST




ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	UKL-0630-04-00-00-0	COOLANT BOOTLE ASSY	1
2	DZW-0212-12-00-00-0	SPOKE HANDLE ASSY	3
3	KLC-000037	5 MM HEX WRENCH WITH HANDLE	1
4	PAS-000008	SAFETY STRAP	1
5	SKR-000017	PLASTIC BOX	1




ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	SLN-0630-01-00-00-0	MOTOR - 115V	1
1	SLN-0630-01-00-00-1	MOTOR - 230V	1
2	SRB-000083	HEX SOCKET HEAD CAP SCREW M5x16	4
3	PDK-000044	SPRING WASHER 5.1	4
4	PDK-000017	ROUND WASHER 5.3	4
5	WKR-000413	CROSS RECESSED PAN HEAD SCREW M5x6	2
6	MCW-0630-06-00-00-0	COOLANT BOTTLE BRACKET	1
7	WKR-000395	HEX SOCKET ROUND HEAD SCREW WITH FLANGE M5x20	2

ITEM	PART NUMBER	DESCRIPTION	Q-TY
8	PDK-000151	NYLON WASHER 8.1x14x3	4
9	OSL-0630-05-00-00-0	GUARD	1
10	SPR-000030	PUSH SPRING	2
11	TLJ-0399-06-00-00-0	BOTTOM SLEEVE	2
12	SRB-000119	HEX SOCKET HEAD CAP SCREW M6x30	4
13	RDK-0630-02-00-00-0	GEARBOX ASSY	1
14	PRS-000019	EXTERNAL RETAINING RING 28z	1
15	TLJ-000010	SELF-LUBRICATING SLEEVE 28x32x16	2
16	SRB-000118	HEX SOCKET HEAD CAP SCREW M6x30	2
17	PDK-000046	SPRING WASHER 6.1	4
18	SRB-000115	HEX SOCKET HEAD CAP SCREW M6x25	2
19	PRS-0440-11-02-00-0	BRAKE RING 20x28x3,9	1
20	WLK-0630-03-02-00-0	PINION SHAFT	1
21	WKR-000434	CROSS RECESSED COUNTERSUNK HEAD SCREW M4x20	1
22	PDK-000060	EXTERNAL TOOTH LOCK WASHER 4.3	2
23	NKR-000013	HEX NUT M4	2
24	WZK-0563-03-10-00-0	SAFETY WIRE SET	1
25	WKR-000193	CROSS RECESSED PAN HEAD SCREW M4x8	1
26	PDK-000016	ROUND WASHER 4.3	2
27	STR-0257-04-03-00-3	MODULE - 115V	1
27	STR-0257-04-03-00-2	MODULE - 230V	1
28	MSK-0599-04-01-00-0	PANEL PLATE	1
29	PDK-000161	EXTERNAL TOOTH LOCK WASHER 3.7	3
30	WKR-000415	CROSS RECESSED PAN HEAD SELF-TAPPING SCREW 3.5x13	3
31	PNK-000013	MAGNET SWITCH	1
32	WLC-000005	START-STOP SWITCH - 115V	1
32	WLC-000007	START-STOP SWITCH - 230V	1
33	WZK-0242-04-00-00-0	REED RELAY WIRE SET ASSY	1
34	PDS-0630-03-03-00-0	MAGNETIC BASE ASSY	1
35	SZN-0075-00-51-00-5	POWER CORD 120V 3x2.08 WITH STRAIN RELIEF ASSY (US)	1
35	SZN-0212-10-02-00-2	POWER CORD 230V 3x1.5 WITH STRAIN RELIEF ASSY (EU)	1
35	SZN-0212-10-02-00-5	POWER CORD 230V 3x1.5 WITH STRAIN RELIEF ASSY (AU)	1
35	PWD-0212-10-02-00-6	POWER CORD 230V 3x1.5 WITH STRAIN RELIEF ASSY (INDIA)	1
35	PWD-0212-10-02-00-7	POWER CORD 230V 3x1.5 WITH STRAIN RELIEF ASSY (UK)	1
36	DLW-000007	CABLE GLAND WITH STRAIN RELIEF PG11	1



ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	WKR-000526	TORX PAN HEAD SCREW 4x25	2
2	WKR-000527	TORX PAN HEAD SCREW 4x35	2
3	PKR-0630-01-04-00-0	STATOR COVER	1
4	OBD-0630-99-01-00-0	MOTOR COVER WITH STATOR ASSY - 230V	1
4	OBD-0630-99-01-00-1	MOTOR COVER WITH STATOR ASSY - 115V	1
5	WKR-000506	SCREW FOR PLASTIC 3x10	2
6	PKR-0563-01-09-00-0	BRUSH COVER	2
7	WKR-000192	CROSS RECESSED PAN HEAD SCREW M4x6	4
8	PDK-000060	EXTERNAL TOOTH LOCK WASHER 4.3	4
9	PDK-000015	ROUND WASHER 4.3	4
10	SCZ-000035	BRUSH – 115V	2
10	SCZ-000036	BRUSH – 230V	2
11	OBD-0630-01-06-01-0	STATOR HOUSING ASSY – 115V	1
11	OBD-0630-01-06-01-1	STATOR HOUSING ASSY – 230V	1
12	SCT-000013	BRUSH HOLDER	2
13	WKR-000300	SCREW FOR PLASTIC 4x16	4
14	OBD-0563-01-07-00-0	FAN COVER	1
15	WKL-000046	BEARING INSERT	1
16	WRN-0630-01-03-00-0	ROTOR ASSY - 115V	1
16	WRN-0630-01-03-00-1	ROTOR ASSY - 230V	1
17	LOZ-000158	BALL BEARING 12x28x8	1
18	PRS-000003	EXTERNAL RETAINING RING 12z	1
19	PKR-0630-99-00-00-0	GEARBOX COVER ASSY	1
20	PRS-000356	INTERNAL RETAINING RING 28w	1
21	LOZ-000025	BALL BEARING 12x28x8	1
22	PKR-0630-01-02-01-1	GEARBOX COVER	1
23	LOZ-000006	NEEDLE BEARING 8x12x10	1
24	LOZ-000057	BALL BEARING 9x24x7	1
25	PDK-000017	ROUND WASHER 5.3	4
26	PDK-000044	SPRING WASHER 5.1	4
27	WKR-000525	TORX PAN HEAD TAPPING SCREW 5x30	4
28	WZK-0630-01-01-00-0	MOTOR WIRE SET	1
29	PRP-000005	CABLE GLAND PG9	2



ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	KLK-000051	DOWEL PIN 5n6x30	1
2	WDZ-0630-02-07-00-0	SLIPPER ASSY	1
3	KOL-0630-02-03-00-0	GEAR z42 z54	1
4	WPS-0563-02-20-00-1	KEY 4x4x25	1
5	WLK-0630-02-04-00-0	PINION SHAFT z12	1
6	PDK-000164	SPACER WASHER 12x18x1	1
7	WLK-0630-02-02-00-0	PINION SHAFT ASSY	1
8	PDK-0211-00-16-00-0	BEARING WASHER 8.1	1
9	PRS-000322	EXTERNAL RETAINING RING 24z	1
10	KOL-0630-02-05-00-0	GEAR z45	1
11	WPS-0630-02-08-00-0	KEY 6x6x16	1
12	LOZ-000047	BALL BEARING 25x47x12	1
13	LOZ-000006	NEEDLE BEARING 8x12x10	1
14	LOZ-000171	NEEDLE BEARING 12x18x12	1
15	KLK-000045	DOWEL PIN 5n6x12	1
16	PKT-0563-02-12-00-0	SHORT SHIFT KNOB ASSY	1
17	ZTR-000001	BALL LOCK 8	1
18	PRS-000346	INTERNAL RETAINING RING 36w	1
19	KNC-0234-00-10-00-0	HOSE FITTING	1
20	KLK-000096	DOWEL PIN 5n6x22	1
21	LST-0630-02-01-02-0	GEAR RACK	1
22	SRB-000115	HEX SOCKET HEAD CAP SCREW M6x25	1
23	TLJ-000038	SELF-LUBRICATION SLEEVE 20/23x25	4
24	KLM-0630-02-09-00-0	GUIDE	2
25	PRS-000245	SEAL 30x42x7	2
26	WRZ-0630-02-06-00-0	SPINDLE ASSY	1
27	PRS-000021	EXTERNAL RETAINING RING 30z	1
28	WKR-000036	HEX SOCKET SET SCREW WITH FLAT POINT M12x10	1
29	SPR-0630-02-06-02-0	SPRING	1
30	LOZ-000049	BALL BEARING 30x55x13	1
31	KRP-0630-02-06-01-0	SPINDLE BODY	1
32	USZ-0279-02-01-06-0	SEAL	1
33	WYP-0630-02-06-03-0	PLUNGER	1
34	PRS-000009	INTERNAL RETAINING RING 19w	1
35	WKR-000032	HEX SOCKET SET SCREW WITH FLAT POINT M10x10	2
36	PRS-000343	INTERNAL RETAINING RING 55w	1
37	SRB-000079	HEX SOCKET HEAD CAP SCREW M5x12	1
38	ZCZ-0630-02-07-02-0	SLIPPER BRACKET	1
39	WLK-0630-02-07-01-0	SLIPPER SHAFT	1