




WE-350DS

HORIZONTAL METAL CUTTING BAND SAW

*Study Carefully Before Operating



Specifications

Capacity:			
90°	270mm	260x260mm	350x220mm
45°	240mm	220x220mm	240x160mm
60°	160mm	150x150mm	
45°(L)	210mm	180x180mm	180x180mm

Blade Size
27 x 0.9 x 3160mm

Blade Speed
50Hz 4P 68m/min
8P 34m/min

Motor
2HP (1.5kW) 4P 1430RPM

Floor Space (L xWxH)
2100mm x 1200mm x 1960mm

Container Loads
18 sets per 20 feet
NW: 360kgs **GW:** 410kgs

Contents

Chapter 1

ACCIDENT PREVENTION AND SAFETY REGULATION

1.1 Advice for the operator	2
1.2 The electrical equipment according to European Standard" CENELEC EN 60 204-1" (1992).....	2
1.3 Emergencies according to European Standard "CENELEC EN 60 204-1 (1992)"	2

Chapter 2

MACHINE DIMENSIONS TRANSPORT INSTALLATION DISMANTLING

2.1 Machine dimensions	2
2.2 Assembling the Saw and the Base.....	2
2.3 Minimum requirements for housing the machine..	3
2.4 Anchoring the machine	3
2.5 Instructions for assembly of the loose parts and accessories	3
2.6 Deactivation of machine	3
2.7 Dismantling	3

Chapter 3

THE MACHINE'S FUNCTIONAL PARTS

3.1 The saw arm	3
3.2 Controls.....	4
3.3 Vice adjustment	4
3.4 Cutting angle adjustment	5
3.5 The base	5
3.6 Saw frame return stroke-limiting device	5
3.7 The operation cycle	5

Chapter 4

ADVICE ON USING YOUR BANDSAW

4.1 Recommendations and advice for using the machine	6
--	---

Chapter 5

ADJUSTING YOUR MACHINE

5.1 Blade tension assembly	7
5.2 Adjusting the blade guide	7
5.3 Changing the blade.....	7
5.4 Adjusting the blade to the flywheels	8

Chapter 6

ROUTINE AND SPECIAL MAINTENANCE

6.1 Daily maintenance	8
6.2 Weekly maintenance	8
6.3 Monthly maintenance	8
6.4 Six-monthly maintenance	8
6.5 Maintenance of other machine parts	8
6.6 Oils for lubricating coolant	8
6.7 Oil disposal	9
6.8 The gear box	9
6.9 Special maintenance	9

Chapter 7

TECHNICAL CHARACTERISTICS

7.1 Table of cutting capacity and technical details	9
---	---

Chapter 8

MATERIAL CLASSIFICATION AND CHOICE OF TOOL

8.1 Definition of materials	10
8.2 Selecting blade	10
8.3 Teeth pitch	10
8.4 Cutting and advance speed.....	10
8.5 Blade running-in	10
8.6 Blade structure	10
8.7 Blade type.....	11

Chapter 9

NOISE TESTS	11
-------------------	----

Chapter 10

WIRING DIAGRAM	12
----------------------	----

Chapter 11

TROUBLESHOOTING

11.1 - Blade and cut diagnosis	13
11.2 - Electrical components diagnosis.....	17

Chapter 12

MACHINE COMPONENTS

12.1 Parts list.....	18
12.2 Explosion drawings.....	21

1 ACCIDENT PREVENTION AND SAFETY REGULATION

This machine has been designed to comply with national and community accident-prevention regulations. Improper use and/or tampering with the safety devices will relieve the manufacturer of all responsibility.

1.1 Advice for the operator

- Check that the voltage indicated on machine motor is the same as the line voltage.
- Check the efficiency of your electric supply and grounding system; connect the power cable of the machine to the socket and the ground lead (yellow-green in color) to the grounding system.
- When the saw frame is in suspended mode (or raised) the blade must not move.
- Only the blade section used for cutting must be kept unprotected. To remove guards operate on the adjustable head.
- It is forbidden to use the machine without its shields
- Always disconnect the machine from the power socket before blade change or carrying out any maintenance job, even in the case of abnormal machine operation.
- Always wear suitable eye protection.
- Never put your hands or arms into the cutting area while the machine is operating.
- Do not shift the machine while it is cutting.
- Do not wear loose clothing like: shirts with sleeves that are too long, gloves that are too big, bracelets, chains or any other object that could get caught in the machine during operation. Tie back long hair.
- Keep the area free of equipment, tools, or any other object.
- Perform only one operation at a time. Never have several objects in your hands at the same time. Keep your hands as clean as possible.
- All internal operations, maintenance or repairs, must be performed in a well-lit area or where there is sufficient light from extra sources so as to avoid the risk of even slight accidents

1.2 The electrical equipment according to European Standard "CENELEC EN 60 204-1" which assimilates, with some integrating modifications, the publication "IEC 204-1 (1992)"


- The electrical equipment ensures protection against electric shock as a result of direct or indirect contact. The active parts of this equipment are housed in a box to which access is limited by screws that can only be removed with a special tool; the parts are fed with alternating current as low voltage (24V). The equipment is protected against splashes of water and dust.
- Protection of the system against short circuits is ensured by means of rapid fuses and grounding; in the event of a motor overload, protection is provided by a thermal probe.
- In the event of a power cut, the specific start-up button must be reset.
- The machine has been tested in conformity with point 20 of EN 60204

1.3 Emergencies according to European Standard "CENELEC EN 60 204-1 (1992)"

- In the event of incorrect operation or of danger conditions, the machine may be stopped immediately by pressing the red mushroom button.
 - The casual or voluntary removal of the blade cover of the flywheels causes the stepping-in of a interlock switch that automatically stops all machine functions.
 - In case blade breakage, the tension release microswitch disconnects all machine functions.
- NOTE: Resetting of machine operation after each emergency stop requires specific restart button.


2 MACHINE DIMENSIONS TRANSPORT INSTALLATION DISMANTLING

2.1 Machine dimensions



2.2 Assembling the Saw and the Base

- Join panels A, B, and C by inserting tenon into mortise as shown in circle diagram 1 and 2.
- Fasten bottom panel D into the joined panels A, B, and C using set screws that are provided
- Attach panel F to panel C with provided set screws.
- Attach control box with two provided set screws.
- Mount the saw unit on the base as shown in drawing 5.
- Fasten the saw unit to the base with provided set screws.




If the machine needs to be moved in its own packing, use a forklift truck or sling it with straps as illustrated in drawing 6 above.

2.3 Minimum requirements for housing the machine

- Main voltage and frequency must comply with the machine's motor requirements.
- Environment temperature should fall within $-10\text{ }^{\circ}\text{C}$ to $+50\text{ }^{\circ}\text{C}$.
- Relative humidity cannot be over 90%.

2.4 Anchoring the machine



Position the machine on a firm cement floor, maintaining, at the rear, a minimum distance of 800 mm from the wall; anchor it to the ground as shown in the diagram, using screws and expansion plugs or tie rods sunk in cement, ensuring that it is sitting level.

2.5 Instructions for assembly of the loose parts and accessories

Fit the components supplied:

Detail 1 Mount bar-stop rod

Detail 2 Mount and align the roll-supporting arm as per the counter-vice table.

2.6 Disactivation of machine

- If the sawing machine is to be out of use for a long period, it is advisable to proceed as follows:
 - 1) Detach the plug from the electric supply panel
 - 2) Loosen blade

- 3) Release the arch return spring
- 4) Empty the coolant tank
- 5) Carefully clean and grease the machine
- 6) If necessary, cover the machine.

2.7 Dismantling (due to deterioration and/or obsolescence)

General rules

If the machine is to be permanently demolished and/or scrapped, divide the material to be disposed of according to type and composition, as follows:

- 1) Cast iron or ferrous materials, composed of metal alone, are secondary raw materials, so they may be taken to an iron foundry for re-smelting after having removed the contents (classified in point 3).
- 2) Electrical components, including the cable and electronic material (magnetic cards, etc.), fall within the category of material classified as being assimilated to urban waste according to the laws of your local, state, or federal government, so they may be set aside for collection by the public waste disposal service;
- 3) Old mineral and synthetic and/or mixed oils, emulsified oils and greases are considered hazardous or special refuse, so they must be collected, transported and disposed of at a special waste disposal service.

NOTE: The standards and legislation concerning refuse is in a constant state of evolution, therefore is subject to changes. The user must keep informed of the regulations at the time of disposal as these may differ from those described above.


3 THE MACHINE'S FUNCTIONAL PARTS

3.1 The saw arm





Machine part consisting of drive members (gear motor or variable speed motor, flywheels), tightening and guide (blade tightening slide, blade guide blocks) of tool.




3.2 Controls



- A. Hydraulic Flow control valve
- B. Hydraulic regulation valve
- J. Trigger Switch



- C. Fork handle
- S. Spring knob
- C1. Manual position
- C2. Auto position



- D. Manual/Auto selector
- E. Start/Reset push button
- F. Speed selector
- G. Main connect switch
- H. Indicator light
- K. Emergency push button

3.3 Vice adjustment

- The device does not require any particular adjustment; in case of excess play of the sliding guide, tighten slide screw more.


To move the vise in either direction, the vise jaw must be unlocked at two points.

- Release the track support by turning handle (1) counter-clockwise.
- Release the vise by moving the lever (2) to the left.
- The vise (5) may now be moved to right position (7) or left position (6) by pushing it with one hand on the vise and the other hand on the track handle (1).
- Once in position, move the lever (2) to the right to lock it into position. If the lever (2) is not between the vise/bed mounts and facing the user, then the vise will not be able to lock. If the vise lever (2) has gone beyond or is obstructed by a vise/bed mount, then use the following procedures.
- Adjust the lever (2) by grasping at the pivot point (P) and lowering it, which may assist in the adjustment. The lever can now be freely rotated into a more convenient position. Some movement of the vise jaw may be required. Raise the lever (2) then move to the right to lock.
- Lock the track support (1) by turning handle clockwise.

Clamping the Work Piece

- Place work piece between the jaws.
- Use the hand wheel to approach the vise jaws to the work piece, leaving 3-4mm of space. Lock down work piece and raise the lever (4). Push start button (E). When the cutting cycle is finished, release vise by lowering lever (4). Upon releasing the lever (4), the vise jaw will open to the same distance that was set initially. This allows for rapid loading of same size material.

3.4 Cutting angle adjustment



Cutting at angles


- Using the right side, angles can be cut up to 60 degrees. This requires that vise jaw to be set on the left side (6). Use the procedures for 3.2 *Vise Adjustment* to place it in left side position.
- Using the left side, angles can be cut up to 45 degrees. This requires the vise jaw to be set on the right side (7). Use the procedures for 3.2 *Vise Adjustment*, to place it in right side position.
- Unlock lever (3) and use the handle under the control box to rotate the saw frame arm until you reach mechanical stop and check if the index corresponds to 45 degrees; if not, operate on the set screws to make measures meet.

3.5 The base

- A structure supporting the SAW ARM (revolving arm for gradual cutting and respective blocking system), the VICE, the BAR STOP, the ROLLER for the support of the material. The base houses the cooling liquid TANK and PUMP.




3.6 Saw frame return stroke-limiting device



The hydraulic cylinder is ideal for the cutting of thin or STAINLESS STEEL section bars, that determines a constant lowering and consequently a good efficiency of the blade throughout the work phase. By adjusting the flow control valve (A), this device can be accommodated to the different situations and applications. Defectiveness in the control of the lowering may be caused by the drop in braking power of the device due to the long-term blowby of the braking fluid.

3.7 The operation cycle


Before operating, all the main organs of the machine must be set in optimum conditions.



Operation Procedure:

A. Trigger switch operation


- Close the hydraulic flow control valve (A) by turning the valve clockwise all the way to the end.
- Raise the saw arm.
- Lift the spring knob (S) to release the pin from its slot. This will free the fork handle (C). Move the handle to the manual position (C1). Lift the spring knob (S) and secure its pin into its slot.
- Use manual/auto selector (D) to select handle icon.
- Select cutting speed by turning speed selector (F). Turtle is low speed, rabbit is high speed, and 'O' is neutral.
- Turn main connect switch (G) to the ON position. Check that the indicator light (H) is on.
- Load work piece and clamp it properly.
- Fully open the hydraulic flow regulation valve (B) by turning the valve counter-clockwise all the way to the end.



- Press trigger switch (J) to start operation.
- If cutting pipe with thin walls, reduce the saw arm descent rate by adjusting the flow control valve (A)
- Press the emergency push button (K) down to shut off all functions. To release the emergency push button rotate the mushroom shaped button (K) clock-wise. The button will pop up and then the cutting cycle can be restarted.
- In general, start cuts by slightly turning hydraulic flow control valve (A) counter-clockwise from 2 to 3 to control the saw arm descent rate. If the arm descends too quickly, turn the hydraulic flow regulation valve (B) clockwise all the way back to stop its descent. A saw arm dropping too quickly can cause the blade to stall on the work piece and the machine will shut off. Push down on emergency push button (K) to immediately stop all machine functions.

- Press the emergency push button (K) down to shut off all functions. To release the emergency shut off rotate emergency push button (K) clock-wise. The button will pop up and then the cutting cycle can be restarted.
- In general, start cuts by slightly turning hydraulic flow control valve (A) counter-clockwise from 2 to 3 to control the saw arm descent rate. If the arm descends too quickly, turn hydraulic flow regulation valve (B) clockwise all the way back to stop its descent. A saw arm dropping too quickly can cause the blade to stall on the work piece and the machine will shut off. Push down on emergency push button (K) to immediately stop all machine functions.

BLADE CUTTING DIRECTION




4 ADVICE ON USING YOUR BANDSAW

4.1 Recommendations and advice for using the machine


The machine has been designed to cut metal building materials, with different shapes and profiles, used in workshops, turner's shops and general mechanical structural work,

Only one operator is needed to use the machine, that must stand as shown in the picture.




B. Auto cutting operation

- Close the hydraulic flow control valve (A) by turning the valve clockwise all the way to the end.
- Raise the saw arm.
- Lift the spring knob (S) to release the pin from its slot. This will free the fork handle (C). Move the handle to the auto position (C2). Lift the spring knob (S) and secure its pin into its slot.
- Use manual/auto selector (D) to select auto.
- Select cutting speed by turning speed selector (F). Turtle is low speed, rabbit is high speed, and 'O' is neutral.
- Turn main connect switch (G) to the ON position. Check that the indicator light (H) is on.
- Load work piece and clamp it properly.
- Press start/reset button (E) to start machine. Check that the blade is running in the correct direction.
- Slightly pull the saw arm down to get rid of air bubbles from the hydraulic cylinder.
- Adjust hydraulic flow control valve (A) by slightly turning the valve counter-clockwise to let saw arm descend and start cutting.



- Before starting each cutting operation, ensure that the part is firmly clamped in the vice and that the end is suitably supported.
- These figures below show examples of suitable clamping of different section bars, bearing in mind the cutting capacities of the machine in order to achieve a good efficiency and blade durability.




- Do not use blades of a different size from those stated in the machine specifications.
- If the blade gets stuck in the cut, release the running button immediately, switch off the machine, open the vice slowly, remove the part and check that the blade or its teeth are not broken. If they are broken, change the tool.
- Before carrying out any repairs on the machine, consult the dealer.

5 ADJUSTING YOUR MACHINE

5.1 Blade tension assembly

The ideal tension of the blade is achieved rotating the handwheel until it the microswitch, that actuates the operation of the machine is actuated
WARNING: the position of this switch is factory set during inspection, after having tightened the blade on the lengthening values indicated by its manufacturer as per specific dimensions set with the help of a special instrument. When replacing the blade, if the thickness and the width differ, it will be necessary to correct the projection of the switch. For this purpose we suggest to strictly select blades having the same features as mounted originally.



5.2 Adjusting the blade guide




- Disconnect the machine from the power source.
- Use a Hex. Wrench to loosen Hex. Socket screw (A) on the square lock plate.

- Hold the handle (B) and slide blade guide block as close as possible to the material without interfering with the cut
- Tighten the Hex. Socket screw (A).
- Reconnect the machine to power source.

Blade guide blocks

The blade is guided by means of adjustable pads set in place during inspection as per the thickness of the blade with minimum play as shown in the figure.



In case the blade needs to be replaced, make sure to always install 0.9mm thick blades for which the blade guide pads have been adjusted. In the case of toothed blades with different thicknesses adjustment should be carried out as follows:

- Loosen nut (C), screw (B) and loosen dowel (D) widening the passage between the pads.
- Loosen the nuts (H) and the dowels (I) and rotate the pins (E - G) to widen the passage between the bearings (F).
- To mount the new blade: place the pad (A) on the blade, loosening the dowel, allow a play of 0.04 mm for the sliding of the toothed blade, lock the relative nut and screw (B), Rotate the pins (E - G) until the bearings rest against the blade as indicated in the figure and then secure the dowels (I) and nut (H).
- Make sure that between the blade and the upper teeth of the pad (L) this is at least 0.2 - 0.3 mm of play; if necessary, loosen the screws that fasten the blocks and adjust accordingly.

BEFORE PERFORMING THE FOLLOWING OPERATIONS, THE ELECTRIC POWER SUPPLY AND THE POWER CABLE MUST BE COMPLETELY DISCONNECTED.


5.3 Changing the blade

To change the blade:

- Lift the saw arm.
- Loosen the blade with the handwheel, remove the mobile blade-guard cover, open the flywheel guards and remove the old blade from the flywheels and the blade guide blocks.
- Assemble the new blade by placing it first between the pads and then on the race of the flywheels, paying particular attention to the cutting direction of the teeth.
- Tension the blade and make sure it perfectly fits inside the seat of the flywheels.


- Assemble the mobile blade-guide end, the flywheel guard, and fasten it with the relative knobs. Check that the safety microswitch is activated otherwise when electric connection will be restored the machine will not start.

5.4 Adjusting the blade to the flywheels




1. Loosen the hex nut screws A, B, and C.
 2. Use an Allen wrench on setscrew D to adjust the tilt of the flywheel.
- Turning the setscrew, D clockwise will tilt flywheel so that the blade will ride closer to the flange.
 -Turning the setscrew, D counter-clockwise will tilt the flywheels so the blade will ride away from the flange. If the blade rides away too far then it will come off.

After the adjustment is finished, fasten the hex nut screws in this order: A, B, and C.



Checking the adjustment of the blade



Use a strip of scrap paper and slide it between the blade and the flywheel while it is running.
 -if the paper is cut then the blade is riding too close to the flange. Re-adjust.
 -if you notice that the blade is riding away from the flange. Then re-adjust.

WARNING: Always assemble blades having dimensions specified in this manual and for which the blade guide heads have been set; otherwise, see chapter on "Description of the operating cycle" in the section Starting-up.

6 ROUTINE AND SPECIAL MAINTENANCE

THE MAINTENANCE JOBS ARE LISTED BELOW, DIVIDED INTO DAILY, WEEKLY, MONTHLY AND SIX-MONTHLY INTERVALS. IF THE FOLLOWING OPERATIONS ARE NEGLECTED, THE RESULT WILL BE PREMATURE WEAR OF THE MACHINE AND POOR PERFORMANCE.

6.1 Daily maintenance

- General cleaning of the machine to remove accumulated shavings.
- Clean the lubricating coolant drain hole to avoid excess fluid.
- Top off the level of lubricating coolant.
- Check blade for wear.
- Rise of saw frame to top position and partial slackening of the blade to avoid useless yield stress.
- Check functionality of the shields and emergency stops.

6.2 Weekly maintenance

- Thorough cleaning of the machine to remove shavings, especially from the lubricant fluid tank.
- Removal of pump from its housing, cleaning of the suction filter and suction zone.
- Clean the filter of the pump suction head and the suction area.
- Use compressed air to clean the blade guides (guide bearings and drain hole of the lubricating cooling).
- Cleaning flywheel housings and blade sliding surfaces on flywheels.

6.3 Monthly maintenance

- Check the tightening of the motor flywheel screws.
- Check that the blade guide bearings on the heads are perfect running condition.
- Check the tightening of the screws of the gear motor, pump, and accident protection guarding.

6.4 Six-monthly maintenance

- Continuity test of the equipotential protection circuit.

6.5 Maintenance of other machine parts

The worm drive gearbox mounted on the machine is maintenance-free guaranteed by its manufacture.

6.6 Oils for lubricating coolant


Considering the vast range of products on the market, the user can choose the one most suited to their own

requirements, using as reference the type SHELL LUTEM OIL ECO. THE MINIMUM PERCENTAGE OF OIL DILUTED IN WATER IS 8 - 10 %.

6.7 Oil disposal

The disposal of these products is controlled by strict regulations. Please see the Chapter on "Machine dimensions Transport - Installation" in the section on *Dismantling*.

6.8 The gear box



The gear box requires periodic changing of oil. The oil must be changed by the first 6 months of a new machine and every year thereafter.

To change the gear box oil

- Disconnect the machine from the power source.
- Raise the saw arm to vertical position
- Release the drain hold (O) to draw off gear oil by loosening the hex socket screw (P).
- Replace the screw (P) after oil completely flows off.

- Place the saw arm back to horizontal position.
- Fill Gear box with approximately .3 liter of gear oil through the hole of the vent screw (Q)




For reference, use SHELL type gear oil or Mobile gear oil #90.

6.9 Special maintenance

Special maintenance must be conducted by skilled personnel. We advise contacting your nearest dealer and/or importer. Also the reset of protective and safety equipment and devices (of the reducer), the motor, the motor pump, and other electrical components requires special maintenance.

7 TECHNICAL CHARACTERISTICS

7.1 Table of cutting capacity and technical details

CUTTING CAPACITY			
0°	270	260x260	350x220
45°	240	220x220	240x160
60°	160	150x150	
45°(L)	210	180x180	180x180

TYPES OF STEEL						CHARACTERISTICS		
USE	I UNI	D DIN	F AF NOR	GB SB	USA. AISI-SAE	Hardness BRINELL HB	Hardness ROCKWELL HRB	R=N/mm ²
Construction steels	Fe360	St37	E24	---	---	116	67	360÷480
	Fe430	St44	E28	43	---	148	80	430÷560
	Fe510	St52	E36	50	---	180	88	510÷660
Carbon steels	C20	CK20	XC20	060 A 20	1020	198	93	540÷690
	C40	CK40	XC42H1	060 A 40	1040	198	93	700÷840
	C50	CK50	---	---	1050	202	94	760÷900
	C60	CK60	XC55	060 A 62	1060	202	94	830÷980
Spring steels	50CrV4	50CrV4	50CV4	735 A 50	6150	207	95	1140÷1330
	60SiCr8	60SiCr7	---	---	9262	224	98	1220÷1400
Alloyed steels for hardening and tempering and for nitriding	35CrMo4	34CrMo4	35CD4	708 A 37	4135	220	98	780÷930
	39NiCrMo4	36CrNiMo4	39NCD4	---	9840	228	99	880÷1080
	41CrAlMo7	41CrAlMo7	40CADG12	905 M 39	---	232	100	930÷1130
Alloyed casehardening steels	18NiCrMo7	---	20NCD7	En 325	4320	232	100	760÷1030
	20NiCrMo2	21NiCrMo2	20NCD2	805 H 20	4315	224	98	690÷980
Alloyed for bearings	100Cr6	100Cr6	100C6	534 A 99	52100	207	95	690÷980
Tool steel	52NiCrMoKU	56NiCrMoV7C100K	---	---	---	244	102	800÷1030
	C100KU	C100W1	---	BS 1	S-1	212	96	710÷980
	X210Cr13KU	X210Cr12	Z200C12	BD2-BD3	D6-D3	252	103	820÷1060
	58SiMo8KU	---	Y60SC7	---	S5	244	102	800÷1030
Stainless steels	X12Cr13	4001	---	---	410	202	94	670÷885
	X5CrNi1810	4301	Z5CN18.09	304 C 12	304	202	94	590÷685
	X8CrNi1910	---	---	---	---	202	94	540÷685
	X8CrNiMo1713	4401	Z6CDN17.12	316 S 16	316	202	94	490÷685
Copper alloys Special brass Bronze	Aluminium copper alloy G-CuAl11Fe4Ni4 UNI 5275					220	98	620÷685
	Special manganese/silicon brass G-CuZn36Si1Pb1 UNI5038					140	77	375÷440
	Manganese bronze SAE43 - SAE430					120	69	320÷410
	Phosphor bronze G-CuSn12 UNI 7013/2a					100	56,5	265÷314
Cast iron	Gray pig iron G25					212	96	245
	Spheroidal graphite cast iron GS600					232	100	600
	Malleable cast iron W40-05					222	98	420

ELECTRIC MOTOR-BLADE ROTATION	kW	0.75 / 1.5
REDUCTION UNIT IN OIL BATH	I	40:1
FLYWHEEL DIAMETER	mm	380
BLADE DIMENSIONS	mm	27x0.9x3160
BLADE SPEED CUTTING	m/min	34 / 68
OPENING VICE	mm	355
SAW FRAME TILTING	°	40
WORKING TABLE HEIGHT	mm	900
MACHINE WEIGHT	kg	360

8 MATERIAL CLASSIFICATION AND CHOICE OF TOOL

Since the aim is to obtain excellent cutting quality, the various parameters such as hardness of the material, shape and thickness, transverse cutting section of the part to be cut, selection of the type of cutting blade, cutting speed and control of saw frame lowering. These specifications must therefore be harmoniously combined in a single operating condition according to practical considerations and common sense, so as to achieve an optimum condition that does not require countless operations to prepare the machine when there are many variations in the job to be performed. The various problems that crop up from time to time will be solved more easily if the operator has a good knowledge of these specifications.

8.1 Definition of materials

The table above lists the characteristics of the materials to be cut. So as to choose the right tool to use.

8.2 Selecting blade

First of all the pitch of the teeth must be chosen, in other words, the number of teeth per inch (25,4 mm) suitable for the material to be cut, according to these criteria:


- Parts with a thin and/or variable section such as profiles, pipes and plate, need close toothing, so that the number of teeth used simultaneously in cutting is from 3 to 6;
- Parts with large transverse sections and solid sections need widely spaced toothing to allow for the greater volume of the shavings and better tooth penetration;
- Parts made of soft material or plastic (light alloys, mild bronze, Teflon, wood, etc.) also require widely spaced toothing;
- Pieces cut in bundles require combo tooth design.

8.3 Teeth pitch

As already stated, this depends on the following factors:


- **Hardness of the material**
- **Dimensions of the section**
- **Wall thickness.**

THICKNESS mm	Z CONTINUOUS TOOTH DESIGN	Z COMBO TOOTH DESIGN
TILL 1.5	14	10/14
FROM 1 TO 2	8	8/12
FROM 2 TO 3	6	6/10
FROM 3 TO 5	6	5/8
FROM 4 TO 6	6	4/6
MORE THAN 6	4	4/6



S = THICKNESS

SOLID Ø OR L mm	Z CONTINUOUS TOOTH DESIGN	Z COMBO TOOTH DESIGN
TILL 30	8	5/8
FROM 30 TO 60	6	4/6
FROM 40 TO 80	4	4/6
MORE THAN 90	3	3/4



Ø = DIAMETER L = WIDTH

8.4 Cutting and advance speed

The cutting speed (m/min) and the advance speed (cm²/min = area traveled by the disk teeth when removing shavings) are limited by the development of heat close to the tips of the teeth.

- The cutting speed is subordinate to the resistance of the material ($R = N/mm^2$), to its hardness (HRC) and to the dimensions of the widest section.
- Too high an advance speed (= lowering of the saw frame) tends to cause the disk to deviate from the ideal cutting path, producing non rectilinear cuts on both the vertical and the horizontal plane.

The best combination of these two parameters can be seen directly examining the chips.

Long spiral-shaped chips indicate ideal cutting.

Very fine or pulverized chips indicate lack of feed and/or cutting pressure.

Thick and/or blue chips indicate overload of the blade.

8.5 Blade running-in

When cutting for the first time, it is good practice to run in the tool making a series of cuts at a low advance speed (= 30-35 cm²/min on material of average dimensions with respect to the cutting capacity and solid section of normal steel with $R = 410-510 N/mm^2$). **Generously spraying the cutting area with lubricating coolant.**

8.6 Blade structure

Bi-metal blades are the most commonly used. They consist of a silicon-steel blade backing by a laser welded high speed steel (HSS) cutting edge. The type of stocks are classified in M2, M42, M51 and differ from each other because of their major hardness due to the increasing percentage of Cobalt (Cc) and molybdenum (Mo) contained in the metal alloy

8.7 Blade type

They differ essentially in their constructive characteristics, such as:

- **Shape** and cutting **angle** of tooth
- **Pitch**
- **Set**

Shape and angle of tooth

REGULAR TOOTH: 0° rake and constant pitch.




Most common form for transversal or inclined cutting of solid small and average cross-sections or pipes, in laminated mild steel and gray iron or general metal.

POSITIVE RAKE TOOTH: 9° - 10° positive rake and constant pitch.




Particular use for crosswise or inclined cuts in solid sections or large pipes, but above all harder materials (highly alloyed and stainless steels, special bronze and forge pig iron).

COMBO TOOTH: pitch varies between teeth and consequently varying teeth size and varying gullet depths. Pitch varies between teeth, which ensures a smoother, quieter cut and longer blade life owing to the lack of vibration.



Another advantage offered in the use of this type of blade in the fact that with an only blade it is possible to cut a wide range of different materials in size and type.

COMBO TOOTH: 9° - 10° positive rake.



9 NOISE TESTS


The test was held under environmental noise levels of 65db. Noise measurements with the machine operating unload was 71db. Noise level during the cutting of mild carbon steel was 73db.

NOTE: with the machine operating, the noise level will vary according to the different materials being processed. The user must therefore assess the intensity and if necessary provide the operators with the necessary personal protection, as required by Law 277/1991.

This type of blade is the most suitable for the cutting of section bars and large and thick pipes as well as for the cutting of solid bars at maximum machine capacity. Available pitches: 3-4/4-6.

SETS

Saw teeth bent out of the plane of the saw body, resulting in a wide cut in the workpiece.



REGULAR OR RAKER SET: Cutting teeth right and left, alternated by a straight tooth.



Of general use for materials with dimensions superior to 5 mm. Used for the cutting of steel, castings and hard nonferrous materials.

WAVY SET: Set in smooth waves.



This set is associated with very fine teeth and it is mainly used for the cutting of pipes and thin section bars (from 1 to 3 mm).

ALTERNATE SET (IN GROUPS): Groups of cutting teeth right and left, alternated by a straight tooth.




This set is associated with very fine teeth and it is used for extremely thin materials (less than 1mm).

ALTERNATE SET (INDIVIDUAL TEETH): Cutting teeth right and left.



This set is used for the cutting of nonferrous soft materials, plastics and wood.

10 WIRING DIAGRAMS



910414-V4

11 TROUBLESHOOTING

This chapter lists the probable faults and malfunctions that could occur while the machine is being used and suggests possible remedies for solving them.

The first paragraph provides diagnosis for TOOLS and CUTS the second for ELECTRICAL COMPONENTS.


11.1 - Blade and cut diagnosis

FAULT

PROBABLE CAUSE

REMEDY

TOOTH BREAKAGE



Too fast advance

Wrong cutting speed

Wrong tooth pitch

Chips sticking onto teeth and in the gullets or material that gums

Defects on the material or material too hard

Ineffective gripping of the part in the vice

The blade gets stuck in the material

Starting cut on sharp or irregular section bars

Poor quality blade

Previously broken tooth left in the cut

Cutting resumed on a groove made previously

Vibrations

Wrong tooth pitch or shape

Insufficient lubricating, refrigerant, or wrong emulsion

Decrease advance, exerting less cutting pressure. Adjust the braking device.

Change speed and/or type of blade. See chapter on "**Material classification and blade selection**", in the section *Blade selection table according to cutting and feed speed*.

Choose a suitable blade. See Chapter "**Material classification and blade selection**".

Check for clogging of coolant drain holes on the blade-guide blocks and that flow is plentiful in order to facilitate the removal of chips from the blade.

Material surfaces can be oxidized or covered with impurities making them, at the beginning of the cut, harder than the blade itself, or have hardened areas or inclusions inside the section due to productive agents used such as casting sand, welding wastes, etc. Avoid cutting these materials or in a situation a cut has to be made use extreme care, cleaning and remove any such impurities as quickly as possible.

Check the gripping of the part.

Reduce feed and exert less cutting pressure.

Pay more attention when you start cutting.

Use a superior quality blade.

Accurately remove all the parts left in.

Make the cut elsewhere, turning the part.

Check gripping of the part.

Replace blade with a more suitable one. See "**Material classification and blade selection**" in the *Blade Types* section. Adjust blade guide pads.


Check level of liquid in the tank. Increase the flow of lubricating refrigerant, checking that the hole and the liquid outlet pipe are not blocked. Check the emulsion percentage.

FAULT

PROBABLE CAUSE

REMEDY


PREMATURE BLADE WEAR



- Faulty running-in of blade
- Teeth positioned in the direction opposite the cutting direction
- Poor quality blade
- Too fast advance
- Wrong cutting speed
- Defects on the material or material too hard
- Insufficient lubricating refrigerant or wrong emulsion

- See "**Material classification and blade selection**" in the *Blade running-in* section.
- Turn teeth in correct direction.
- Use a superior quality blade.
- Decrease advance, exerting less cutting pressure. Adjust the braking device.
- Change speed and/or type of blade. See chapter on "**Material classification and blade selection**", in the section *Blade selection table according to cutting and feed speed*.
- Material surfaces can be oxidized or covered with impurities making them, at the beginning of the cut, harder than the blade itself, or have hardened areas or inclusions inside the section due to productive agents used such as casting sand, welding wastes, etc. Avoid cutting these materials or perform cutting with extreme care, cleaning and remove such impurities as quickly as possible.
- Check level of liquid in the tank. Increase the flow of lubricating coolant, checking that the coolant nozzle and pipe are not blocked. Check the emulsion percentage.

BLADE BREAKAGE




- Faulty welding of blade
- Too fast advance
- Wrong cutting speed
- Wrong tooth pitch
- Ineffective gripping of the part in the vice
- Blade touching material at beginning of cut
- Remedy

- The welding of the blade is of utmost importance. The meeting surfaces must perfectly match and once they are welded they must have no inclusions or bubbles; the welded part must be perfectly smooth and even. They must be evenly thick and have no bulges that can cause dents or instant breakage when sliding between the blade guide pads.
- Decrease advance, exerting less cutting pressure. Adjust the braking device.
- Change speed and/or type of blade.
- See chapter on "**Material classification and blade selection**", in the section *Blade selection table according to cutting and feed speed*.
- Choose a suitable blade. See Chapter "**Material classification and blade selection**".
- Check the gripping of the part.
- At the beginning of the cutting process, never lower the saw arm before starting the blade motor.

FAULT

PROBABLE CAUSE

REMEDY



Blade guide pads not regulated or dirty because of lack of maintenance

Blade guide block too far from material to be cut

Improper position of blade on flywheels

Insufficient lubricating coolant or wrong emulsion

Check distance between pads (see "**Machine adjustments**" in the *Blade Guide Blocks* section): extremely accurate guiding may cause cracks and breakage of the tooth. Use extreme care when cleaning.

Approach head as near as possible to material to be cut so that only the blade section employed in the cut is free, this will prevent deflections that would excessively stress the blade.

The back of blade rubs against the support due to deformed or poorly welded bands (tapered), causing cracks and swelling of the back contour.

Check level of liquid in the tank. Increase the flow of lubricating refrigerant, checking that the hole and the liquid outlet pipe are not blocked. Check the emulsion percentage.

STEAKED OR ETCHED BANDS

Damaged or chipped blade guide pads

Tight or slackened blade guide bearings.

Replace them.

Adjust them (see Chapter "**Machine adjustments**" in *Blade guide section*).

CUTS OFF THE STRAIGHT

Blade not parallel as to the counter service

Blade not perpendicular due to the excessive play between the guide pads and maladjustment of the blocks

Too fast advance

Worn out blade

Wrong tooth pitch

Check fastenings of the blade guide blocks as to the counter-vice so that they are not too loose and adjust blocks vertically; bring into line the position of the degrees and if necessary adjust the stop screws of the degree cuts.

Check and vertically re-adjust the blade guide blocks; reset proper side guide play (see Chapter "**Machine adjustments**" in *Blade guide section*).

Decrease advance, exerting less cutting pressure. Adjust the braking device.

Approach it as near as possible to material to be cut so that only the blade section employed in the cut is free, this will prevent deflections that would excessively stress the blade.

Replace it. Blade with major density of teeth is being used, try using one with less teeth (see **Chapter "Material classification and blade selection"** in the *Blade Types* section).


FAULT

PROBABLE CAUSE

REMEDY

	Broken teeth Insufficient lubricating refrigerant or wrong emulsion	Irregular work of the blade due to the lack of teeth can cause deflection in the cut; check blade and if necessary replace it. Check level of liquid in the tank. Increase the flow of lubricating coolant, checking that the hole and the liquid outlet pipe are not blocked. Check the emulsion <i>percentage</i> .
--	--	--

FAULTY CUT	Worn out flywheels Flywheel housing full of chips	The support and guide flange of the band are so worn out that they cannot ensure the alignment of the blade, causing faulty cutting; blade rolling and drawing tracks can have become tapered. Replace them. Clean with compressed air.
-------------------	--	---

STREAKED CUTTING SURFACE 	Too fast advance Poor quality blade Worn out blade or with chipped and/or broken teeth Wrong tooth pitch Blade guide block too far from material to be cut Insufficient lubricating coolant or wrong emulsion	Decrease advance, exerting less cutting pressure. Adjust the braking device. Use a superior quality blade. Replace it. Blade used probably has too large teeth, use one with more teeth (see "Material classification and blade selection" in the <i>Blade Types</i> section). Approach it as near as possible to material to be cut so that only the blade section employed in the cut is free, this will prevent deflections that would excessively stress the blade. Check level of liquid in the tank. Increase the flow of lubricating coolant, checking that the hole and the liquid outlet pipe are not blocked. Check the emulsion percentage.
---	--	--

NOISE ON GUIDE BLOCKS	Chipped bearings Worn out or damaged pads	Dirt and/or chips between blade and guide bearings. Replace them. Replace them.
------------------------------	--	---

11.2 - Electrical components diagnosis

<u>FAULT</u>	<u>PROBABLE CAUSE</u>	<u>REMEDY</u>
<p>THE BAND ROTATION MOTOR DOES NOT WORK</p>	<p>“SA1” two-speed switch</p> <p>“FR1” band motor over-load relay</p> <p>“SB1” emergency switch</p> <p>“SA2” start push button</p>	<p>It must be exactly turned towards Rabbit or Turtle sign.</p> <p>Push down FR1 red button. After a motor cooling time of 5 minutes, if there is no current continuity on these two wires, the motor must be replaced.</p> <p>Reset emergency switch (see operation procedure).</p> <p>Check the functioning and/or possible damages. If so, replace it.</p>
<p>MACHINE DOES NOT WORK</p>	<p>Fuses “FU”</p> <p>“SQ1” Automatic shutoff limit switch</p> <p>“SQ2” blade cover limit switch</p> <p>“SQ3” blade broken limit switch</p> <p>Speed switch “SA1” in position “0”</p> <p>Emergency button “SB1” on</p> <p>“SB2” trigger switch</p> <p>Motor “M1”</p>	<p>Check electrical efficiency. If not, replace the fuse.</p> <p>Refer to the operation procedure and adjust the switch if machine doesn't shut off after the material completely cuts. Replace it if it damaged.</p> <p>Check closing of the fly wheel cover. Check the efficiency of the device; replace it if damaged.</p> <p>Check the efficiency of the device; replace it if damaged.</p> <p>It must be exactly turned to Rabbit or Turtle sign.</p> <p>Reset the emergency switch by following the steps of Operation Procedure. Check electrical efficiency, if not, replace it.</p> <p>Check the efficiency of the device; replace it if damaged.</p> <p>Check current continuity on the two wires in the prone, if not, replace the motor.</p>
<p>MOTOR STOPPED WITH PILOT LIGHT “HL2” LIT</p>	<p>“SB2” trigger switch</p> <p>Motor “M 1”</p>	<p>Check the efficiency of the device; replace it if damaged.</p> <p>Check that it is not burnt and that it turns freely. Replace it if damaged.</p>

PART LIST

Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
1	Base (Bottom Plate)		1	47	Roller		1
2	Base (Left Part)		1	48	Ball Bearing	6004ZZ	2
2-1	Nut	M8	4	48-1	C-Ring	S-20	2
3	Base (Right Part)		1	49	Roller Shaft		1
4	Base (Front Part)		1	50	Hex. Socket Cap Screw	M10x20	2
4-1	Hex. Cap Bolt	M8x16	4	50-1	Spring Washer	M10	2
4-2	Washer	M8	8	60A	Handle		1
5	Hex. Cap Bolt	M12x40	2	60-1	Hex. Socket Cap Screw	M8x20	2
6	Nut	M12	2	60-2	Nut	M8	2
8	Hex. Cap Bolt	M8x16	6	61	Handle		1
8-1	Washer	M8x18x2	6	62	Nut	M12	1
9-	Plate		1	63	Locking Lever		1
10	Hex. Socket Cap Screw	M5x8	4	63-1	Set Screw	M10x16	1
11	Coolant Tank		1	64	Hex. Socket Cap Screw	M10x35	1
12	Hex. Cap Bolt	M8x16	2	64-1	Spring Washer	M10	1
13	Coolant Gauge		1	65	Shaft Nut		1
13-1	Nut	M10	2	65-1	Oil Seal		1
13-2	Washer	M10	2	65-3	Disk		1
14	Hex. Cap Bolt	3/16"	2	65-4	Spring Washer	M8	4
15	Tank Cover		1	65-5	Hex. Socket Cap Screw	M8x35	4
16	Filter		1	66A	Shaft		1
17	Pump		1	68	Swivel Arm		1
18	Hex. Socket Cap Screw	M6x25	2	68-1	Hex. Cap Bolt	M10x35	1
18-1	Washer	M6x13x1	2	69	Scale	0-60°	1
22	Hose Clamp	13mm	1	69-1	Scale	0-45°	1
23	Hose	5/16"x235cm	1	70	Rivet	2.3x4	4
23-1	Hose	1"x45cm	1	71	Pin		1
24A	Coolant and Chip Tray		1	72	Hollow Pin	Ø 2.5x16	1
24-1	Plate		4	73	Spring		1
24-2	Hex. Cap Bolt	M10x20	4	74	Bushing		1
24-3	Nut	M10	4	75	Bracket		1
24-4A	Block Plate		1	76	Spring Washer	M8	2
25	Mounting Bracket		2	77	Hex. Socket Cap Screw	M8x25	2
26	Spring Washer	M10	4	78	Knob		1
27	Hex. Socket Cap Screw	M10x20	4	79	Jam Nut	M40	1
28	Washer	M10x21x2	4	80	Star Washer	M40	1
29	Hex. Cap Bolt	M10x20	4	81	Anti-Dust Cover	M40	2
29-1	Washer	M10	4	82	Ball Bearing	32008	2
30	Hex. Cap Bolt	M12x40	2	83A	Shaft		1
31	Nut	M12	2	84	Hex. Cap Bolt	M10x45	1
36	Emergency Switch		1	85	Nut	M10	2
37-1	Hole Cover	HP-25	2	86A	Pointer		2
37-2	Hole Cover	HP-19	1	87	Hex. Socket Cap Screw	M5x8	2
38-1	Hole Cover	HP-22	1	88A	Cover		1
39	Track		1	88-1	Hollow Pin	Ø 6x20	2
40	Hex. Socket Cap Screw	M8x35	2	88-2	Set Screw	M8x10	1
40-1	Nut	M8	2	89	Hex. Socket Cap Screw	M8x35	5
40-2	Spring Washer	M8	2	89-1	Spring Washer	M8	5
41	Set Screw	M6x12	4	92A	Table		1
42	Washer		1	92-1	Set Screw	M6x12	1
43	Handle	M8x25	1	92-2	Changeable Plate		1
44	Roller Stand		1	92-3	Hex. Socket Cap Screw	M8x20	4
45	Hex. Cap Bolt	M12x25	2	94	Bar-Stop-Rod		1
46	Spring Washer	M12	2	95A	Bar Bracket		1
46-1	Washer	M12x28x3	2	95-1	Nut	M8	2

1011001

PART LIST

Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
95-2	Hex. Socket Cap Screw	M8x25	1	147-1	Indicator Light		1
95-3	Knob	M8x30	1	147-2	Main Connect Switch		1
95-4	Stop Bar		1	147-5	Speed Selector		1
97	Scale		1	147-6	Start Push Button		1
98	Rivet		3	147-7	Manual/ Auto Selector		1
99	Chip Gutter		1	147-8	Control Panel		1
100	Hex. Socket Cap Screw	M6x8	2	148	Electrical Box Cover		1
102	No-Burr Jaw		1	149	Supporting Bracket		1
103	Hex. Socket Cap Screw	M6x15	2	149-1	Shaft		1
104	Counter Vise Jaw		1	150	Set Screw	M8x10	1
105	Hex. Socket Cap Screw	M6x15	2	150-1	Hex. Socket Cap Screw	M8x20	4
106	Vise Jaw		1	150-2	Spring Washer	M8	4
107	Flat Head Machine Screw	M6x15	2	151	Reduction Unit		1
108A	Vise		1	151-1	Vent Screw		1
109	Dovetail Plate		1	152	Key	8x8x30	1
110	Nut	M5	3	153	Hex. Cap Bolt	M8x25	4
111	Set Screw	M5x25	3	153-1	Spring Washer	M8	4
113	Key	5x5x15	1	154	Motor		1
115	Spring Washer	M8	4	154-1	Junction Box		1
116	Hex. Socket Cap Screw	M8x20	4	155	Key	8x7x35	1
117	Hand Wheel		1	186	Hex. Socket Cap Screw	M10x35	4
117-1	Spring Washer	M6	1	186-1	Spring Washer	M10	4
117-2	Hex. Socket Cap Screw	M6x25	1	193B	Saw Arm		1
117-3	Bushing		1	193-1	Set Screw	M8x10	2
118	Set Screw	M8x10	1	194	Hex. Socket Cap Screw	M10x35	4
120A	Vise Seat		1	194-1	Spring Washer	M10	4
122	Vise Setting Plate		1	195	Limit Switch		1
123	Hex. Socket Cap Screw	M10x30	2	195-1	Switch Pin		1
124	Washer	3/4"x37x3	1	196	Hex. Socket Cap Screw	M4x35	2
125	Lock Lever Device		1	197	Hex. Socket Cap Screw	M10x35	4
127	Handle		1	197-1	Spring Washer	M10	4
128	Setting Plate		1	198A	T Connector		1
129	Bushing		1	199	Hex. Socket Cap Screw	M5x10	2
130	Hex. Socket Cap Screw	M8x20	2	200	Coolant Switch		2
130-1	Spring Washer	M8	2	201	Hose Clamp	13mm	1
131	Electric Box Holder		1	203	Pipe Fitting	1/4Px5/16	1
132	Spring Washer	M8	4	204	Hose	5/16"x40cm	1
133	Hex. Socket Cap Screw	M8x20	4	205	Hose	5/16"x90cm	1
135	Hex. Socket Cap Screw	M10x25	2	206	Drive Flywheel		1
136	Spring Washer	M10	2	207	Washer		1
138	Hex. Socket Cap Screw	M6x25	2	207-1	Spring Washer	M10	1
138-1	Washer	M6	2	208	Hex. Cap Bolt	M10x25	1
139	Nut	M6	2	209A	Idle Flywheel Shaft		1
142	Hex. Socket Cap Screw	M5x8	10	210	Roller Bearing	32007	2
143	Nut	M5	4	211	Idle Flywheel		1
144	Electric Box Platform		1	212	Star Washer	M35	1
144-1	Transformer		1	212-1	Anti-dust Cover	M35	2
144-2	Fuse Block	2A	1	213	Jam Nut	M35	1
144-3	Magnetic Switch		1	214	Oil Inlet	1/16	1
144-4	Overload Relay		1	215A	Saw Blade		1
144-5	Terminal Strip		1	216B	Blade Cover		1
144-6	Insulation Plate		1	216A-1	Extension		1
144-7	Electric Parts Plate		1	216A-2	Round Head Screw	M6x8	2
144-8	Grounding Plate		1	217	Plum Screw	M6x10	4
146	Round Head Screw	M5x10	4	219	Round Head Screw	M4x8	2


1011001

PART LIST

Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
220	Nut	M4	2	282	Set Screw	M5x5	1
222	Handle		2	283	Set Bushing		1
223	Handle Wheel		1	284	Hex. Cap Screw	M6x12	2
223-1	Thrust Bearing	51103	1	285	Washer	M6x13x2	2
223-2	Blade Tension Gauge		1	286A	Lead Screw		1
223-3	Plate		1	286-1	Spring		1
224	Special Spring Washer		10	286-2	Hex. Socket Cap Screw	M8x16	1
225	Tension Shaft		1	286-3	Washer	M8	1
229	Plate		1	287	Setting Seat		1
230	Hex. Socket Cap Screw	M6x12	2	288	Lead Screw Seat		1
230-1	Washer	M6	2	289	Bearing Bushing		1
231	Limit Switch		1	289-1	Ball Bearing	51104	1
232	Hex. Socket Cap Bolt	M4x25	2	289-2	Nut		1
239	Nut	M16	1	289-3	Set Screw	M5x5	1
240A	Slide Bracket		1	291	Trigger Switch		1
240A-1	Spring Washer	M10	3	292	Pipe		1
240A-2	Hex. Socket Cap Screw	M10x45	3	292-1	Nut	M16	1
240A-3	Set Screw	M10x25	1	293	Nut	M12	1
244	Cover Plate		1	294	Spring Hook		1
245	Hex. Socket Cap Screw	M6x8	2	295	Spring		1
246	Gib		2	296	Spring Seat		1
247	Spring Washer	M8	6	297	Spring Bushing		1
248	Hex. Socket Cap Screw	M8x20	6	298	C-Ring	S-12	4
249	Blade Guide Movable Rod		1	298-1	Washer	M10	2
249-1	Hex. Socket Cap Screw	M6x8	1	299	Shaft		1
250	Set Screw	M6x12	4	300	Pin		1
251	Hex. Socket Cap Screw	M8x20	2	301	Hollow Pin	2.5x16	1
252	Setting Bracket		1	302	Spring		1
253	Hex. Socket Cap Screw	M12x50	1	303	Fork		1
254	Handle		1	304	Nut	M10	1
256	Guide Bracket		1	305	Adjusting Bracket		1
259	Bolt		2	306	Shaft		1
260	Hex. Socket Cap Screw	M6x8	1	307	Knob		1
261	Blade Guard		1	307-1	Bushing		1
262	Set Screw	M6x20	2	308	Shaft		1
263	Nut	M6	2	309	Arm		1
264	Centric Shaft		2	310	C-Ring	S-12	2
265	Ball Bearing	608ZZ	8	311	Hex. Socket Cap Screw	M10x25	1
265-1	Ball Bearing	608ZZ	2	312	Spring Washer	M10	1
266	E-Ring	E-7	4	313	Post		1
267	Blade Guide		2	314	Set Screw	M10x16	3
268	Hex. Socket Cap Screw	M6x25	2	315	Hydraulic Cylinder Post		1
269	Eccentric Shaft		2	316	Spring Washer	M8	4
270	Hex. Socket Cap Screw	M6x8	2	317	Hex. Socket Cap Screw	M8x25	4
271	Blade Guard		1	318	Round Head Screw	M5X10	2
272	Guide Bracket		1	319	Limit Switch		1
272-1	Hex. Socket Cap Screw	M6x8	2	320	Hex. Socket Cap Screw	M6X8	2
273	Pipe Fitting	1/4Px5/16	2	320-1	Washer	M6	2
274	Blade Guide		2	321A	Adjusting Bracket		1
275	Ball Bearing Bracket		1	322A	Hydraulic Cylinder		1
276	Set Screw	M6x12	4	323	Hex. Socket Cap Screw	M10X40	1
277	Hex. Socket Cap Screw	M10x20	2	324	Nut	M10	1
279	Hex. Socket Cap Screw	M8x20	2				
280	Brush		1				
281	Brush Clamp		1				


1011001

WE-350DS




1011001-V4


WE-350DS



1011001-V5



WE-350DS



1011001-V4

EC DECLARATION OF CONFORMITY

according to the following EC Directive

- Machinery Directive : 2006/42/EC.
- EMC Directive : 2004/108/EC.
- LV Directive : 2006/95/EC.
- ROHS Directive : 2002/95/EEC

The undersigned, Kuo Chuan-Lin, representing Way Train Industries Co., Ltd. No. 1008, Hou Chuang Rd., Pei Tun Chu, Taichung, Taiwan, R.O.C., manufacturer, declares that the machine described hereafter:

Bandsaw for metalworking,

Model: WE-350 Series

Provided that it is used and maintained in accordance with the generally accepted codes of good practice and the recommendations of the instruction manual, meets the essential safety and health requirements of the Machinery Directive, EMC Directive, EC Low Voltage Directive, and RoHs Directive.

For the most specific risks of this machine, safety and compliance with the essential requirements of the Directive has been based on elements of:

- The European Standard EN 13898: 2009 - Machine tools – Safety – Sawing machines for cold metal.
- The European Standard EN 60204-1: 2006/AC:2010 – Safety for the electrical equipment of machinery.
- The European Standard IEC 61000-6-2: 2005 – Electromagnetic compatibility (EMC) – Part 6.2 – Generic standards – Immunity for industrial environments.
- The European Standard IEC 61000-6-4:2007+A1/2010 – Electromagnetic compatibility (EMC) – Part 6.4 – Generic standards – Emission standards for industrial environments.
- The European Standard EN ISO 12100:2010 ; Safety of machinery – General principles for design- Risk assessment and risk reduction.
- The International Standard ISO 13850:2008- Safety of Machinery – Emergency stop – Principle for design.
- The International Standard ISO 13857: 2008; Safety of machinery - Safety distances to prevent danger zones being reached by the upper limbs and lower limbs.

2013, 10

Date: _____

Signature: Kuo-Chuan Lin

Qualification : General Manager